

# **FreeRTOS**

"It is the fate of operating systems to become free."

- Neal Stephenson

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts

March 30, 2017

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hooks

Heap Memo

Queues

#### Introduction

- Architecture and Licensing
- High level services
- Cortex-M interrupts
- Kernel, Tasks, Hooks Heap
- Queues, Semaphore, Mutex
- Task notification



FIEERIOS

Prof. Erich Styger

#### Introduction

FreeRTOS Licensing

Architecture

Cortex-M Interrupts

ernel Contro

Ιαοκο

Hooks

łeap Memory

Queues

Semaphore and Mutex

#### Introduction

- http://www.freertos.org
- Maintained by Real Time Engineers Ltd., London (Richard Barry)
- Open Source, free-of-charge, royalty free
- >35 architectures, >113'000 downloads in 2015
- Portable, simple to learn and use
- Ecosystem and commercial supported ports available
  - OpenRTOS: commercial supported version
  - SafeRTOS: special version dedicated to safety critical systems
  - Sold Reference Manual/Tutorial Book (protected PDF with watermark, no print/copy)

Prof. Erich Styger

#### Introduction

FreeRTOS Licensin
Distributions

Architecture

Cortex-M Interrupts

errier Conti


ιαοκο

HOOKS

Heap Memory

Queues

# **UBM Embedded Market Study**



<sup>&</sup>lt;sup>2</sup>Source: http://tech.ubm.com

Prof. Erich Styger

#### Introduction

FreeRTOS Licensing

. . . .

Cortex-M Interrupts

Kernel Contro

rasks

Hooks

Heap Memo

Queues

Semaphore and Mutex

#### Services and Features

- Scheduler
- Tasks with multiple priority lists
- Dynamic memory (heap)
- Coroutines
- Message queue
- Software timer
- Semaphore and Mutex
- Event set
- Direct task notification
- Thread Local Storage pointers
- Low Power and Tickless Idle Mode
- Trace

Prof. Erich Styger

Introduction

Distributions

Architecture

Cortex-M Interrupts

Kernel Contro

Ιαοιιο

Hooks

leap Memory

lueues

Semaphore an Mutex

# ► Terms on www.freertos.org/a00114.html


FreeRTOS Licensing

- Open Source, Free of charge, no royalties
- "The modification to the GPL is included to allow you to distribute a combined work that includes FreeRTOS without being obliged to provide the source code for proprietary components"
- Community support: sourceforge.net/projects/freertos
- Can be used in commercial applications, need to contribute back changes in the kernel
- ► If source code is published, FreeRTOS needs to be published too
- Not allowed to publish benchmarks results without permission
- Different licensing terms for OpenRTOS, SafeRTOS and FreeRTOS+ parts

Introduction

Cortex-M Interrupts

### Distributions





- Default distribution: http://www.freertos.org
- Integrated into SDK's (NXP Kinetis SDK, http://www.nxp.com/ksdk) with SDK Processor Expert component
- 3. Advanced Open Source FreeRTOS port and component: sourceforge.net/projects/mcuoneclipse

Architecture

Cortex-M Interrupts


remer conta

Haaka

Heap Memo

Queues

### McuOnEclipse





- https://sourceforge.net/projects/
  mcuoneclipse/
- Latest Open Source FreeRTOS port for S08, S12(X), S12X, DSC, ColdFire V1/V2 and Kinetis
- ▶ Graphical configuration of FreeRTOSConfig.h
- Extra features: Command line shell, Low Power Timer and Tickless Idle mode, Percepio Tracealizer, Segger RTT with SystemViewer

FreeRTOS

Prof. Erich Styger

Introduction
FreeRTOS Licensing
Distributions

Architecture

Cortex-M Interrupts

Kernei Contri

Tasks

10013

\_

zueues

Semaphore an Mutex

### Summary

- FreeRTOS is open source
- Permissible license, allows to link it with my code without affecting license
- Commercial version: OpenRTOS and SafeRTOS
- Processor Expert component
- Multiple Open Source ports available



Introduction

FreeRTOS Licensin
Distributions
Summary

Architecture

Cortex-M Interrupts

verner Conti

140110

Hooks

Heap Memory

Queues

Semaphore and Mutex

Block Diagram Kernel and Interrupts

Cortex-M Interrupts

Kernel Contro

Hooks

Heap Memo

Queues

Semaphore and

# **Architecture**

"It is not the beauty of a building you should look at; its the construction of the foundation that will stand the test of time."

— David Allan Coe

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts

March 30, 2017

### Architecture: Learning Goals

- Know the design philosophy
- Understand source organization
- Apply interrupt model to application



FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Learning Goals

Block Diagram

Kernel and Interrupts

Cortex-M Interrunts

Kernel Control

Hooks

Heap Memory

ueues)

# Philosophy- Kernel

- Small Kernel, implemented in C, compiled and linked with application
- ARM Cortex M0+ and M4(F) ports
- Kernel configuration with #define in FreeRTOSConfig.h
- Preemptive or cooperative scheduler mode (at compile time)
- Kernel only needs tick interrupt and software interrupt
- RTOS creates and runs in IDLE task
- Scheduler variables and task stack in dynamic memory (heap)
- Different selection of heap allocation (schemes)
- Multiple tasks with same priority

#### Introduction

Architecture

Philosophy

Kernel and Interrupts

Cortex-M Interrupt

Kernel Control

Hooks

Heap Memory

ueues

# Philosophy- Ticks

#### operating systems need a time tick

- ► Tick or 'Ticks' provide time base for RTOS
- Counter in tick interrupt
- Typically 10 ms or 1 ms tick period, default max 1 kHz
- ► ARM: SysTick timer, or low power timer (LPTMR on Kinetis), or any periodic timer
- All RTOS time calculations are in ticks!
- Tick frequency/period considerations
  - Interrupt and system load
  - Timing precision

PSP MSP Prof. Erich Styger

#### Introduction

Architecture

Philosophy

Kernel and Interrupts
ARM Cortex-M Interrupts

Cortex-M Interrupts

Kernei Contro

HOOKS

Heap Memory

Queues

# Philosophy- Tasks

- Possible dynamic task creation and deletion
- Task stack and scheduler data structure in dynamic memory (heap)
- Tasks are running with stack in the 'heap'
- Interrupts are running on 'main' stack (MSP)
- Tasks are using PSP stack pointer
- Software interrupt used to switch task context
- Tasks are (usually) staying in an endless loop
- RTOS always creates and runs IDLE task

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Learning Gos Philosophy

Block Diagram

ARM Cortex-M Interrupts

Outex-WilliteHupt


Kernel Control

Hooks

Heap Memory

Queues

# **Block Diagram**





- Only 10 source plus header files for co-routine, queue, event, timer, list and tasks
- FreeRTOS Configuration Header File
- 5 different heap implementations
- Port depending on architecture and tool chain and compiler
- FreeRTOS+: different license

Prof. Erich Styger

Introduction

Architecture Learning Goals

Block Diagram

ARM Cortex-M Interrupts

Cortex-M Interrupts

Kernel Contro

---

Hooks

Heap Memory

ueues

### Kernel and Interrupts

RTOS needs two interrupt sources

► Tick Interrupt: SysTick

Software Interrupt: SVCall, PendableSrvReq

Other interrupts: under application control

Need to care about reentrancy

RTOS does not protect its own data structures

Keep interrupts enabled in RTOS

with this assembly-code

Efficiency and interrupt latency

trigger are executed by trigger

 RTOS API functions with From ISR suffix (e.g. xSemaphoreGiveFrom ISR) use critical sections

Special consideration: interrupt nesting

FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Philosophy

Block Diagram

Kernel and Interrup

ernal Control

Tasks

Hooks

Heap Memory

ueues

#### FreeRTOS

Prof. Erich Styger

#### Introduction

Architecture

Philosophy

Kernel and Interrupts

ARM Cortex-M Interrupts

Cortex-M Interrupts

Kernel Contro

Tasks

Hooks


Hean Me

Juane

ueues

iemaphore ar Mutex


**ARM Cortex-M Interrupts** 



Cortex-M0+: Kernel disables global interrupts

- ► Cortex-M4: using PRIMASK to mask interrupts 0: -> it is disabled (no masking)
  - ► configMAX\_SYSCALL\_INTERRUPT\_PRIORITY
    like BASEPRI -> check it

# ARM Cortex-M Interrupts- Component Settings



- ARM Family and Core Settings
- ► configMAX\_SYSCALL\_INTERRUPT\_PRIORITY
- Interrupt setting for RTOS (lowest!): SysTick, PendSV and SVCall
- Using Systick as tick timer

Philosophy

Block Diagram

Kernel and Interrupts

ARM Cortex-M Interrupts

Cortex-M Interrupts

Kernel Control

.....

HOOKS

leap Memor

Jueues

# Architecture: Summary

- Portable, C, 'Port' with ASM
- Kernel only needs tick and SWI
- Kernel usually does not block all interrupts (blocks all on Cortex M0+!)



- ARM Cortex-M4: configMAX SYSCALL INTERRUPT PRIORITY
- Heap needed for Kernel data and task stacks
- Do **not** call RTOS API from interrupts except FromISR API

Universal Asynchronous Receiver Transmitter UART



Prof. Erich Styger

Introduction

Architecture ARM Cortex-M Interrupts

Cortex-M Interrupts



# **Kernel Control**

"Must is a hard nut to crack, but it has a sweet kernel."

— Charles Spurgeon

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts

March 30, 2017

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goal

Tasks

Hooks

Heap Memory

Queues

# Kernel Control: Learning Goals

- Learn different ways to control the kernel
- Use kernel to create critical sections
- Start/stop/suspend the scheduler
- Apply it for your application



FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Contro

Learning Goals Kernel Control

\_\_\_\_

Hooks

łeap Memory

ueues

Semaphore and Jutex

Learning Goals

Kernel Control vTaskStartSchedul

vTaskEndScheduler vTaskSuspendAll

xTaskResumeAll
taskENTER\_CRITCAL,
taskEXIT\_CRITCAL
taskDISABLE\_INTERRUPT
taskENABLE\_INTERRUPT

Tasks

looks

Heap Memor

Queues

Semaphore and

Starting and stopping the scheduler:

vTaskStartScheduler(), starting vTaskEndScheduler() ending

- Kernel suspending and resuming: vTaskSuspendAll(), vTaskResumeAll()
- ► Passing control to one of the ready tasks: taskYIELD()

### vTaskStartScheduler

void vTaskStartScheduler(void);

ightharpoonup Starts the scheduler (Init ightarrow Running)

► Creates IDLE task (configMINIMAL\_STACK\_SIZE, tskIDLE\_PRIORITY) 0,1,2,3.. MAX (0 is the lowest!, because task)

- Creates the optional timer daemon task.
- Runs the highest priority task
- Does not return until xTaskEndScheduler ()

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goals Kernel Control

vTaskStartScheduler

vTaskEndScheduler
vTaskSuspendAll
xTaskResumeAll
taskENTER\_CRITCAL,
taskEXIT\_CRITCAL
taskDISABLE\_INTERRUPTS
taskENABLE\_INTERRUPTS

Tacke

looks

eap Memory

Queues

### vTaskEndScheduler

void vTaskEndScheduler(void);

- Kernel resources will be released
- ► Task resources (queues, semaphores) are not freed
- Many ports do not implement this function

reeRIOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goal Kernel Control

vTaskStartScheduler

vTaskEndScheduler

vTaskSuspendAll

xTaskResumeAll

taskENTER\_CRITCAL,
taskEXIT\_CRITCAL

taskDISABLE\_INTERRUPT
taskFNARI F\_INTERRUPT

Tasks

looks

eap Memor

Queues

### vTaskSuspendAll

#### void vTaskSuspendAll(void);

- Puts the kernel from Active to Suspended state
- Prevents context switch
- ► Interrupts remain enabled tick interrupts are still running (keeping running)
- Can be called in a nested way

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goals Kernel Control

vTaskStartScheduler

vTaskSuspendAll

xTaskResumeAll
taskENTER\_CRITCAL,
taskEXIT\_CRITCAL
taskDISABLE\_INTERRUPT
taskENABLE\_INTERRUPT

Tasks

looks

eap Memor

Queues

. Samanhar

### xTaskResumeAll

portBASE\_TYPE xTaskResumeAll(void);

- Puts the kernel from Suspended to Active state
- return value
  - pdTRUE: Context switch happened
  - pdFALSE: no context switch or still Suspended (nested)

reeRIOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goals Kernel Control

vTaskStartScheduler

vTaskSuspendAll xTaskResumeAll

taskENTER\_CRITCAL, taskEXIT\_CRITCAL taskDISABLE\_INTERRUPT taskENABLE\_INTERRUPT

Tasks

ooks

eap Memory

Queues

```
void taskENTER CRITICAL(void);
        void taskEXIT CRITICAL(void);
       void vPortEnterCritical(void) {
          portDISABLE INTERRUPTS();
                                          interrupts are disabled even the timer
          uxCriticalNesting++;
                                               do vour stuff in there, but do it fast
       void vPortExitCritical(void) {
10
          uxCriticalNesting --:
          if (uxCriticalNesting == 0) {
11
            portENABLE INTERRUPTS();
13
14
```

- Counter used to count nesting
- Some ports always enable interrupts when count==0
- Do not call FreeRTOS API functions in CS!

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goals Kernel Control

vTaskStartScheduler

vlaskEndScheduler
vTaskSuspendAll
xTaskResumeAll
taskENTER\_CRITCAL,
taskEXIT\_CRITCAL
taskDISABLE\_INTERRUPT:

Tacke

Hooks

Heap Memor

Queues

# taskDISABLE\_INTERRUPTS, taskENABLE\_INTERRUPTS

```
void taskDISABLE_INTERRUPTS(void);

void taskENABLE_INTERRUPTS(void);

#define taskDISABLE_INTERRUPTS() \

portDISABLE_INTERRUPTS() \

#define portDISABLE_INTERRUPTS() \

portSET_INTERRUPT_MASK() \

#define portSET_INTERRUPT_MASK() \

__asm volatile("cpsid i")

#define portCLEAR_INTERRUPT_MASK() \

__asm volatile("cpsie i")
```

- Globally enables and disables interrupts (macros)
  - Cortex-M0+: all interrupts
  - ► Cortex-M4: up to PRIMASK, configMAX\_SYSCALL\_INTERRUPT\_PRIORITY

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Learning Goals Kernel Control

vTaskStartSchedule

vTaskSuspendA xTaskResumeAl

xTaskResumeAll taskENTER\_CRITCAL, taskEXIT\_CRITCAL taskDISABLE\_INTERRUPTS taskENABLE\_INTERRUPTS

taskYIELD

Tasks

looks

Heap Memo

Queues

```
#define taskYIELD()
10
```

```
portYIELD()
#define portYIELD()
                      vPortYieldFromISR()
yield causes an interrupt
void vPortYieldFromISR(void) {
  /* Set a PendSV to request a context switch. */
  *(portNVIC INT CTRL) = portNVIC PENDSVSET BIT;
  /* Barriers are normally not required but do ensure
        the code is completely within the specified
       behavior for the architecture. */
                           barrier instructions: pipline flashing mememory
    asm volatile ("dsb");
   _asm volatile("isb");
```

- Request a context switch with Software Interrupt
- Required for cooperative multitasking
- Typically implemented as macro

Prof. Erich Styger

Introduction

Architecture

Kernel Control

tockVIFI D

### Kernel Control: Summary

- FreeRTOS API to control the kernel
- Different states of kernel (init, running, suspended)
- How to start/stop the scheduler
- Suspending/resuming tasks with interrupts enabled
- Creating Scheduler Critical Sections
- Disabling/Enabling interrupts
- Yielding



.....

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interru

ernel Control

Kernel Control

vTaskStartScheduler

vTaskStartScheduler vTaskEndScheduler vTaskSuspendAll

vTaskSuspendAll
xTaskResumeAll
taskENTER\_CRITCAL,
taskEXIT\_CRITCAL
taskDISABLE\_INTERRUPT:
taskENABLE\_INTERRUPTS

Tooko

Jooks

leap Memo

Queues

Semaphore and Mutex



# **Tasks**

"It seems essential, in relationships and all tasks, that we concentrate only on what is most significant and important."

- Soren Kierkegaard

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Contro

Tasks

. . . . . . . .

earning Goals riority-based Pree

Scheduling

Time Slicing

IDLE Task

Blinky Task

Task Control

ummary ab Task

looks

Heap Memory

Queues

### Tasks: Learning Goals

- Understand preemptive and cooperative mode
- Know FreeRTOS priority numbering
- Overview of task states and transitions
- Apply different options for time slicing
- Understand how the IDLE task works



Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Learning Goals

Priority-based Preemptive Scheduling

ime Slicing DLE Task

lask Contro Summary

\_ab Task

looks

Heap Memory

Queues

#### Tasks: Overview

- FreeRTOS task system: Task transitions
- Kernel and Task Control API
  - Scheduler start and stop
  - Task creating, deleting, suspending and resuming
- Scheduling and Idle Task

Prof. Erich Styger

Introduction

Architecture

Tasks

Learning Goals

#### Prof. Erich Styger

#### Introduction

#### Architecture

#### Cortex-M Interrupts

#### Cernel Control

#### Tasks

Learning Goals

Priority-based Preemptive Scheduling

Task States

LE Task

Task Contro


Summary Lab Task

#### looks

Heap Memory

#### Queues

- configUSE\_PREEMPTION configures preemptive scheduling
- Always run the highest-priority ready task
- Priorities from 0 (lowest) to (configMAX\_PRIORITIES-1)
- Multiple tasks with the same priority: time-slicing
- ► High priority tasks should not starve lower priority tasks



Kernel Contro

Tasks

Learning Goals

Scheduling
Task States

Time Slicing

IDLE Task Blinky Task


Task Conti

ab Task

łooks

Heap Memor

Queues



# Time Slicing



- configUSE\_TIME\_SLICING is default mode: time slicing between highest ready tasks with same priority at tick interrupt time.
- Processing time given to ready task with highest priority
- Tasks with the same priority will time slice

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupt

Kernel Contr

Tasks

Learning Goals

riority-based Preemptive

Time Slicing

DLE Task

Blinky Task

Summary

Summary Lab Task

looks

Heap Memory

Queues

#### **IDI F Task**

- IDLE task always created at scheduler start
- Priority: tskIDLE\_PRIORITY
- ► Stack size: configMINIMAL\_STACK\_SIZE
- ▶ Runs if no other task needs to run
- Frees memory of deleted tasks
  - ► No IDLE starving if using vTaskDelete()
  - ► Otherwise: IDLE starving is fine
- Calls Idle Task Hook
  - Application functionality in idle hook/task
  - ► Common use: enter power saving mode

-reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Learning Goa

Priority-based Preemptive Scheduling

Task States

IDLE Task

Blinky Task

Summary

Lab Task

Hooks

Heap Memory

Queues

- ► Yields if using cooperative scheduler mode
- configIDLE\_SHOULD\_YIELD: yield if ready tasks are available

Introduction

Architecture

Cortex-M Interrup

ernel Control

Tasks

Learning Goals

riority-based Preemptive cheduling

Task States

IDLE Task

iask Control Summary

Summary .ab Task

ioks


eap Memory

Queues

### IDLE Task: configIDLE SHOULD YIELD



- configIDLE\_SHOULD\_YIELD for preemptive scheduler
- Time slicing will distribute time equally among same priority tasks
- CPU cycles wasted in IDLE task



- ► With enabled configIDLE\_SHOULD\_YIELD IDLE task gives CPU time to tasks
- ► No exact time slicing any more

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Learning Goals

riority-based Preemptive

Task States

In F Task

Blinky Task

Task Contr Summary

ummary ab Task

łooks

łeap Memory

Queues

```
10
```

```
BaseType t res;
                                       v: means returns nothing
xTaskHandle taskHndl:
res = xTaskCreate(BlinkyTask, /* function */x: means returns something Cortex-M Interrupts
      "Blinky", /* Kernel awareness name */
      configMINIMAL STACK SIZE+50, /* stack */
      (void*)NULL, /* task parameter */
      tskIDLE_PRIORITY, /* priority */
      &taskHndl /* handle */
if (res!=pdPASS) { /* error handling here */ }
```

- Task function and debug name
- Stack size for task and priority
- Optional task parameter (pvParameters) or NULL
- Optional task handle or NULL
- Check error code (out of memory?)

Prof. Erich Styger

Introduction

Architecture

Tasks

Blinky Task

# Blinky Task

```
static void BlinkyTask(void *pvParameters) {
 for(;;) {
    LED Neg();
```

- ► Tasks are normal functions
- start parameter pvParameters pointer assigned with xTaskCreate()
- Endless loop, does not leave function (except task deletes itself)
- BlinkyTask runs until preempted

```
static void BlinkyTask(void *pvParameters) {
for(;;) {
LED_Neg();
vTaskDelay(50/portTICK_PERIOD_MS);
}
for 1kHz
2 for 500Hz
```

- Avoid starving other task
- portTICK\_PERIOD\_MS: time between two ticks
- vTaskDelay() suspends task for given ticks
- Suspends number of ticks from current tick count

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Kernel Control

Tasks

Learning Goals

Scheduling Task States

DLE Task

Blinky Task

Summary

Lab Task

Hooks

eap Memory

Duelles

```
static void BlinkyTask(void *pvParameters) {
   TickType_t xLastWakeTime = xTaskGetTickCount();
   for(;;) {
      LED_Neg();
      vTaskDelayUntil(&xLastWakeTime, 50/portTICK_PERIOD_MS);
      );
}
```

- xTaskGetTickCount() returns current tick counter
- vTaskDelayUntil() can delay from previous tick counter, independent of task overhead
- xLastWakeTime updated by kernel

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Cernel Control

Task

Learning Goals

riority-based Preemptive

Task States

IDLE Task

Blinky Task Task Contro

Summary Lab Task

ooks

eap Memo

\_

Queues

Cortex-M Interrupts

ernel Control

Tasks

Learning Goals
Priority-based Preemptive
Scheduling

Time Slicin

Blinky Task
Task Control

uxTaskPriorityGet

Summary

-----

łeap Memorv

0.....

Semaphore an

Delaying a task:

vTaskDelay(),vTaskDelayUntil()

Changing the priority at runtime: uxTaskPriorityGet(), vTaskPrioritySet()

Task suspending and resuming:

```
vTaskSuspend(), vTaskResume(),
vTaskResumeFromISR()
```

#### Tasks

Learning Goals

riority-based Preemptive cheduling

Time Slicing

Task Control
uxTaskPriorityGet

vTaskPriorityS Summary

Summary Lab Task

ماده

Heap Memory

Queues

```
unsigned portBASE_TYPE uxTaskPriorityGet( xTaskHandle
    pxTask);
```

- Returns the priority of a task
- NULL argument: priority of calling task
- ► Call only from a task context

### vTaskPrioritySet

void vTaskPrioritySet(xTaskHandle pxTask, unsigned portBASE TYPE uxNewPriority);

- Changes the priority of a task
- NULL argument: priority of calling task
- Call only from a task context

```
xTaskCreate(vTaskCode, "MyTask",
    configMINIMAL STACK SIZE, NULL, tskIDLE PRIORITY,
     &xHandle);
vTaskPrioritySet(xHandle, tskIDLE PRIORITY+1);
```

vTaskPrioritySet

Prof. Erich Styger

Introduction

Architecture

Tasks

#### Tasks: Summary

- Preemptive and non-premptive scheduling
- Task time slicing
- configMINIMAL\_STACK\_SIZE used for IDLE task
- tskIDLE\_PRIORITY is zero and the lowest priority
- Tasks usually run in an endless loop
- Task creation can call out-of-heap error hook
- vTaskDelay() and vTaskDelayUntil()



Prof. Erich Styger

Introduction

Architecture

autou M Inton

rnel Control

Tasks

earning Goals riority-based Preemptive

Time Slicing

Task Contri

Summary Lab Task

Hooks

Heap Memory

Queues

#### Tasks: Lab Task

- Create 'blinky' FreeRTOS tasks
- Task creation outside of scheduler
- Task creation from task
- Using task handle
- Using task startup parameter
- Using vTaskDelay() and vTaskDelayUntil()



.....

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Learning Goals
Priority-based Preemptive

Task States

IDLE Task

Task Contri Summary

Lab Task

ooks

eap Memory

ueues



# Hooks

"Do not bite at the bait of pleasure, till you know there is no hook beneath it."

— Thomas Jefferson

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

HOURS

Overview

dle Hook

Tick Hook

Malloc Failed Hook Stack Overflow Failed Hook

Summary

Heap Memory

Dueues

#### Hooks- Goals



- Understand FreeRTOS hook concept
- Know the different hooks
- Apply and use hooks in application

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Cernel Contro

Hooks

A .....

Idle Hook

Tick Hook

Malloc Failed Hook

Summary

Heap Memory

Dueues

#### Hooks: Overview

 RTOS calls optional application defined callbacks (or hooks)

- Hook function implemented in application
- Available hooks
  - ▶ Idle Hook: called whenever the system is idle
  - ► Tick Hook: called for every system time tick
  - Malloc Failed Hook: called if allocation failed
  - Stack Overflow Hook: called if stack overflow has been detected

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hook

Overview

Idle Hook

Tick Hook

Stack Overflow Failed Hook

eap Memory

ueues

```
void vApplicationIdleHook(void) {
  /* Called whenever the RTOS is idle (from the IDLE task
      ) */
 CPU EnterLowPowerMode(); /* wait for interrupt */
  /* here an interrupt woke us up */
```

- ► Enabled with configUSE\_IDLE\_HOOK
- Called from the IDLE task, whenever the system no user task is running
- Ideal place to go into low power mode
- ▶ Toggle LED/Pin: activity shows idle activity ⇒ Low Power
- ▶ Idle hook function *not* allowed to call blocking API functions!

**Blocking** 

syTaskDelay() -> please me als IDLE task don't do sth for ...ms SemaphoreTake()

Prof. Erich Styger

Introduction

Architecture

Tasks

Idle Hook

- Enabled with configUSE\_TICK\_HOOK
- Called from tick interrupt
- Can be used instead of a dedicated timer running at tick frequency
- Executed in interrupt context, keep it short!
- Only FromISR () RTOS API functions can be called

reeRTOS

Prof. Erich Styger

Introduction

Architectur

Cortex-M Interrupts

ernel Contro

Tasks

Hooks

Overvie

Idle Hook

Tick Hook

Stack Overflow Failed Hook
Summary

leap Memory

Queues

- ► Enabled with configUSE MALLOC FAILED HOOK
- Called if memory allocation failed

for(;;) {} /\* stop for debugging \*/

taskDISABLE INTERRUPTS();

Prof. Erich Styger

Introduction

Malloc Failed Hook

ernel Contro

Tasks

Hooks

Overview Idle Hook

Idle Hook

Stack Overflow Failed Hook

Heap Memory

Queues

Semaphore ar

- ► Enabled with configCHECK\_FOR\_STACK\_OVERFLOWS
- Overflow check adds run-time cost
- ► Method 1: Check SP at task swap time not really faile-save
- ► 'Method 2: Method 1 + checking last 16 bytes pattern

### Hooks: Summary

 Concept: hooks are used as events to notify the application

- Hooks are optional
- Enabled/disabled in FreeRTOSConfig.h
  - Idle Hook: called whenever the system is idle
  - Tick Hook: called for every system time tick
  - Malloc Failed Hook: called if malloc failed
  - Stack Overflow Hook: called if stack overflow has been detected
- Error hooks: disable interrupts and halt system



rieen 103

Prof. Erich Styger

Introduction

Architecture

ortev-M Intern

rnel Contro

Tasks

Hooks

Overview

Idle Hook

Tick Hook

Malloc Failed Hook Stack Overflow Failed Hook

Summary

Heap Memory

ueues

Semaphore ar



# Heap Memory

"A good memory is surely a compost heap that converts experience to wisdom, creativity, or dottiness; not that these things are of much earthly value, but at least they may keep you amused when the world is keeping you locked away or shutting you out."

- Michael Leunig

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hooks

Heap Memory

Learning Goals Heap Schemes

Heap Example

Oueues

### Heap Memory: Learning Goals

- Knowing Memory allocation in FreeRTOS
- Avoid memory fragmentation
- Choosing the right memory scheme
- Using dynamic memory allocation



FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupt

nel Control

Tasks

Hooks

Heap Memory
Learning Goals
Heap Schemes

emory Fragmentatio eap Example

. . . . . .

Queues

### Heap Memory: Overview

- Dynamic memory used by RTOS: configTOTAL\_HEAP\_SIZE
  - Size in bytes
  - ► Tasks stack space
  - RTOS internal structures: TCB Task Control Block
  - Semaphores, Mutex, Queues
  - Application memory through pvPortMalloc()
- Availability: not always available with tool chain
- Efficiency: tuned for small code size
- Thread safe: to be used from multiple threads
- ▶ Deterministic: timing guaranteed within error margin
- Multiple allocation 'Schemes', one selected at configuration time

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hooks

Heap Memoi

Learning Goals
Heap Schemes
Memory Fragmentatio
Heap Example

Queues

#### **Heap Schemes**

- configFRTOS\_MEMORY\_SCHEME
- Custom memory allocation can be added
- 5 predefined allocation 'Schemes'

#### runtime

- 1. Allocation only, deterministic can't free it!
- 2. No block merge, not deterministic, heap fragmentation
- Wrapper to standard malloc()/free(), not deterministic
- 4. Coalesces free blocks, not deterministic rather using this one
- 5. Multiple memory segments, coalesces blocks

Introduction

Architecture

Cortex-M Interrupts

ernel Control


Tasks

Hooks

Heap Memory
Learning Goals
Heap Schemes
Memory Fragmentation
Heap Example

Queues

### Memory Fragmentation: Scheme 2



- Blocks and tasks can be deleted
- Memory blocks are not combined
- Possible memory fragmentation
- Do not use for random allocation/free sequences

-> ok! otherwise it doesn^t workd

if you kill the task and then renew the task with the same size

Prof. Erich Styger

Introduction

Architecture

Tasks

61

Heap Memory
Learning Goals
Heap Schemes
Memory Fragmentation
Heap Example

Queues

Semaphore and Mutex

```
void *pvPortMalloc(size_t xWantedSize);
void vPortFree(void *pv);
size_t xPortGetFreeHeapSize(void);
```

► Check return value if not NULL

```
void foo(void) {
    uint8_t *bufP; /* pointer to buffer */

bufP = (uint8_t*)pvPortMalloc(sizeof("Hello"));

if (bufP==NULL) {
    for(;;); /* ups! Out of memory? */
}

(void) strcpy(bufP, "Hello"); /* copy data */

/* do something with data */
vPortFree(bufP); /* release memory */

11 }
```

### Heap Memory: Summary

- Different heap schemes in FreeRTOS
- Alloc only, no merge, standard malloc, merge, multiple regions
- Problem of determinism and fragmentation
- Used for task stacks and RTOS data structures: queues, semaphore, mutex
- Used by application to allocate/release dynamic memory



FreeRIOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interru

nel Control

Tasks

100KS

Learning Goals
Heap Schemes
Memory Fragmentation
Heap Example

Summary



# Queues

"An Englishman, even if he is alone, forms an orderly queue of one."

— George Mikes

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts

Prof. Erich Styger

Introduction

Architecture

Tasks

Queues

### Queues: Learning Goals

- Understand queues in FreeRTOS
- How to use queues
- Using FIFO and LIFO queues
- How to debug queues



reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Contro

Tasks

Hooks

leap Memory

Queues

Learning Goals

Creating and Deleting Queues


nspecting and Removing

ueue Registry xample: Shell C

Summary

Lab Task

#### Queues: Overview



- List of items, allocated in Heap
- FIFO: First In First Out

LIFO/Stack: Last In - First Out

queues are

- Queues have ability to block caller if queue full or empty
- ▶ RTOS can resume tasks which are blocked on a queue
- FreeRTOS: Enqueue and Dequeue by copy operation

FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interru

rnel Contro

Tasks

Hooks

Heap Memor

Jueues

Learning Goals

Creating and Deleting Queues Inspecting and Removing Items

dding Items Queue Registry

xampie: Sneii C ummary

ab Task

## Creating and Deleting Queues

```
xQueueHandle xQueueCreate(
unsigned portBASE_TYPE uxQueueLength,
unsigned portBASE_TYPE uxItemSize
);
void vQueueDelete(xQueueHandle xQueue);
```



- xQueueCreate(): fixed queue size at creation time
- Returns Queue handle, check for NULL!
- uxQueueLength: maximum number of items in queue
- uxItemSize: element item size in bytes

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memor

Queue:

Creating and Deleting Queues

nspecting and Removini ems addina Items

xample: Shell C ummarv

Lab Task

```
BaseType_t xQueueReset(xQueueHandle xQueue);
BaseType_t xQueuePeek(
xQueueHandle xQueue,
void *pvBuffer,
portTickType xTicksToWait);
BaseType_t xQueueReceive(
xQueueHandle xQueue,
void *pvBuffer,
portTickType xTicksToWait); directly get returned
```

- xQueueReset(): Clear queue
- xQueuePeek (): Inspecting item without removing
- xQueueReceive(): Remove item in front the queue
- pvBuffer: pointer where to copy the item
- xTicksToWait: Waiting ticks/time
  - 0: polling
  - ▶ portMAX DELAY: wait forever

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memor

Queue:

Creating and Deleting Queue
Inspecting and Removing

dding Items

=xampie: Snei Summary

Lab Task

```
BaseType_t xQueueSendToBack(
    xQueueHandle xQueue,
    const void *pvltemToQueue,
    portTickType xTicksToWait);
BaseType_t xQueueSendToFront(
    xQueueHandle xQueue,
    const void *pvltemToQueue,
    portTickType xTicksToWait);
```

- xQueueSendToBack(): FIFO operation
- xQueueSendToFront(): Stack/LIFO operation
- xTicksToWait: Waiting time in case queue is full
- ▶ returns pdPASS or errQUEUE\_FULL

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Contro

Tasks

Hooks

Heap Memor

#### Queues

Creating and Deleting Queues
Inspecting and Removing

#### Adding Items

Queue Registr Example: Shel

Summary

Lab Task

### Queue Registry

```
void vQueueAddToRegistry(
   QueueHandle_t xQueue,
   const char *pcQueueName);
void vQueueUnregisterQueue(QueueHandle_t xQueue);
```

- configQUEUE\_REGISTRY\_SIZE: number of queues for registry maximum number of queues
- vQueueAddToRegistry(): make queue name known
- vQueueUnregisterQueue(): remove queue name from list

NP Queue List (FreeRTOS)							j (i)
#^	Queue Name	Address	Len	Item Size	# T	# R	Queue Type
> 1	RefStartStopSem	0x20000848	0/1	Empty	0	0	Binary Semaphore
2	RefSem	0x200008a0	1/1	Empty	0	0	Mutex
> 3	RadioRxMsg	0x20001138	0/6	0x22 (34 B)	0	0	Queue
> 4	RadioTxMsg	0x20001260	0/6	0x22 (34 B)	0	0	Queue
> 5	RxStdInQ	0x20001388	0/48	0x1 (1 B)	0	0	Queue
maximum of items							

FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

vernei Contro

Tasks

Hooks

Heap Memor

Queues

Learning Goals
Creating and Deleting Queu

Adding Items

Queue Registry

lueue Hegistry xample: Shell C

ummary

ab Task

Cortex-M Interrupt

Kernel Contro

Tasks

Hooks

Heap Memory

Queues

Learning Goals
Creating and Deleting Que


Adding Items

Queue Registry Example: Shell Queue

xample: Shell Q

\_ab Task

Semaphore and



we need to protect the UART, because two Tasks have access on it

- Peripheral sharing
- Inter-Process Communication (IPC)
- ► Consumer-Producer Pattern
- Items: characters or messages

### **Queues: Summary**

- Message passing, data buffering and IPC
- Queues are allocated in heap memory
- Fixed at creation time
- Two-Dimensional arrays of data
- Items 'by value', not 'by reference' items are stored by value
- Queuing in blocking and polling ways



Prof. Erich Styger

Introduction

Architecture

. . . . . . .

rnel Contro

Tasks

Hooks

Heap Memory

#### Queues

Learning Goals

Creating and Deleting Queues Inspecting and Removing

lueue Registry xample: Shell

Summary

Lab Task

```
#define QUEUE LENGTH
                             5
  #define QUEUE ITEM SIZE
                             sizeof(uint8_t*)
3
  void QUEUE SendMessage(const uint8 t *msg) {
     uint8 t *ptr:
     size t strSize = strlen(msg)+1;
     ptr = FRTOS1 pvPortMalloc(strSize);
     (void) UTIL1 strcpy(ptr, strSize, msg);
10
     if (FRTOS1 xQueueSendToBack(
11
         queueHandle, ptr, portMAX DELAY)!=pdPASS)
12
      for(;;){} /* ups?
13
14
15
```

we need to have the address of the ptr, put there an address (&)

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Contro

Tasks

Hook

Heap Memor

Queues

Creating and Deleting Queues
Inspecting and Removing

Queue Registry Example: Shell (

Summary

Lab Task

Semaphore and Mutex

```
static xQueueHandle queue;
   void QUEUE SendMessage(const uint8 t *msg) {
     FRTOS1_xQueueSendToBack(queue, msg, 0) using polling
              -> queue three by three
                                                 if msg = "hello0"
   const uint8_t *QUEUE_ReceiveMessage(void) {
     uint8 t *buffer;
     FRTOS1 xQueueReceive (queue, buffer, 0);
10
     return buffer;
11
12
13
   void QUEUE //nit(void) {
15
              FRTOS1_xQueueCreate(3, 3); queue by: three by three
16
```

Introduction Architecture

Cortex-M Interrupts

Kernel Contro

Tasks

110010

Heap Memor

Jueues

Creating and Deleting Queues
Inspecting and Removing

Adding Items Dueue Registry

Summary

Lab Task

Semaphore and Mutex

rnel Control

Tasks

Hooks

Heap Memor

#### Queues

Learning Goals

Creating and Deleting Queue Inspecting and Removing

Queue Registry Example: Shell C

Summary

Lab Task

Semaphore and Mutex

#### Lab Assignment: Queues

- Implement message passing between tasks with queues
- Multiple tasks use queue to send data to shell task
- Evaluate and discuss 'single char' and 'message' queue variants
- Apply combination of polling and queuing with timeouts





# Semaphore and Mutex

"Quantum Mechanics and General Relativity are both accepted as scientific fact even though they're mutually exclusive."

- Roy H. Williams

Prof. Erich Styger

erich.styger@hslu.ch Lucerne University of Applied Sciences and Arts reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memory

Queue

Semaphore and Mutex

Learning Goals

Synchronization

ojourner Mars Hove riority Inversion

Priority Inversion

Nested Priority Inherita

Priority Ceilin

FreeRTOS Semaph

Mutex Creating Binary Semapho

eues with no Da tex Example

inary Camanhara

ary .

### Semaphore and Mutex: Learning Goals

- Understand why using Synchronization Primitives
- Identify problems of Priority Inversion and Deadlocks
- Apply Priority Inheritance and Priority Ceiling protocols
- Use FreeRTOS Semaphore and Mutex in applications



FreeRIOS

Prof. Erich Styger

Introduction

Architecture

ortex-M Interrup

nel Control

Tasks

looks

Heap Memor

Queues

Semaphore ar

Learning Goals

Access to Shared Resou

Sojourner Mars Ro

Priority Inversion

Priority Inheritance Pr Nested Priority Inherit

Priority Ceilin

Priority Ceiling FreeRTOS Sei

eeRTOS Semaphore utex

ueues with no Da

tex Example

Summary ab Task

#### Semaphore and Mutex- Overview

- RTOS provides ways for communication and synchronization
- ► **Semaphore**: Binary and Counting Semaphore, Mutex
- Problems: Priority Inversion, Deadlocks
- Protocols: Priority Inheritance, Priority Ceiling
- ► **Application**: Resource guard/protection/synchronization, IPC

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memor

Queues

emaphore and

Learning Goals

Access to Shared Resource Synchronization

Sojourner Mars Rov Priority Inversion

Priority Inversion

Priority Inheritance Pr Nested Priority Inherit

Priority Ceilir


FreeRTOS Semaph


Creating Binary Ser

utex Example

ry Semaphore

#### Access to Shared Resource





- Multiple tasks or threads need access to shared resource
- Problems: coordinated access, serialization, critical sections
- ► Need for *Synchronization*

FreeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupt

Kernel Control

Tasks

Hooks

Heap Memory

ueues

Semaphore and

arning Goals

Access to Shared Resource

Sojourner Mars Rov

riority Inversion

Priority Inheritance Pr Nested Priority Inherit

Deadlocks

Priority Ceili

eeRTOS Semaphore lutex

ueues with no Da

utex Example

ту эеппарпог

#### **Synchronization**

- Critical Section
  - Program section, to be executed mutually exclusively
- Semaphore
  - One of synchronization primitives
  - Reentrancy, Critical Section, Atomic processing
- ► Mutual Exclusion or Mutex can help to implement reentrancy
  - Special type of (binary) semaphore
  - Only one task/thread/code will be in critical section
- Notation
  - $\blacktriangleright$  Lock():  $?_x \Rightarrow L_x$
  - Unlock(): U<sub>x</sub>

Tasks

Synchronization

### Sojourner Mars Rover

- Mars Pathfinder mission with Sojourner rover
- Launched 4. Dec. 1996, landed 4. Jul. 1997
- Problem: Occasional resets



<sup>&</sup>lt;sup>6</sup>Source: Wikipedia

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hooks

Heap Memo

Queue:

Semaphore and Mutex

arning Goals

Access to Shared Resource Synchronization Soiourner Mars Rover

Priority Inversion

Nested Priority Inher

Priority Ceiling


eeRTOS Semaphore

Creating Binary Sema

tex Example

nary Semaphore

- ► Priority Inversion
  - Higher priority task blocked by lower priority task
- Indefinite Priority Inversion
  - Possible with medium priority task delaying lower priority task (which blocks high priority task)
- Solution: Priority Inheritance
  - Lower-priority task inherits priority of any higher-priority task pending on resource
  - At resource release: task priority change ends



Prof. Erich Styger

Introduction

Architectur

Jortex-IVI Intern

ernel Control

Tasks

Hook

Heap Memo

Queues

Semaphore and

Learning Goals

rnchronization njourner Mars Rover

Priority Inversion

Priority Inheritance I Nested Priority Inhe

Priority Ceiling


riority Ceiling reeRTOS Semapl

Creating Binary S

utex Example

nary Semaphore

#### Priority Inheritance Protocol



this one has the resouce (NASA using this semphare taking and remove)

- Task holding resource (PL) inherits priority of requesting task (PH)
- Push-Through Blocking: task is blocked by resource usage not of its own

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memor

Queues

emaphore and

arning Goals

cess to Shared Resourd nchronization

urner Mars Hove rity Inversion

Priority Inheritance Protocol Nested Priority Inheritance

Deadlocks Priority Ceiling

FreeRTOS Semapho Mutex


> eating Binary Sema<sub>l</sub> eues with no Data

x Example

ary

Tasks

Nested Priority Inheritance




- ► Nested resource usage:  $L_2 \rightarrow L_1 \rightarrow U_1 \rightarrow U_2$
- Transitive Blocking: caused by not-directly involved semaphore, accessed in a *nested* way by blocking tasks.

Tasks

Deadlocks

#### Priority Inheritance does *not* avoid Deadlocks

Typical deadlock: nested resource usage



it's not connected to the ressource

- Nested resources
- Task gets resource from a class of resources which can be hold by another task of lower/same prio
- Solution with Priority Ceiling
- Resource has Ceiling Priority: Priority of highest task priority using it
- Priority Ceiling Rules
  - R1: normal scheduling (higher priority task preempts lower priority task)
  - R2: only get resource if task priority is higher than the ceiling of all resources currently hold by other tasks
  - R3: normal Priority Inheritance

Introduction

Architecture

ortex-M Interrup

nel Control

Tasks

Hook

Heap Memor

Jueues

emaphore ar

Learning Goals

ynchronization ojourner Mars Rover

ority Inversion

riority Inheritance Prote ested Priority Inheritan

Deadlocks

#### Priority Ceiling

FreeRTOS Semaphore and Mutex


ueues with no Dat

ex Example

ıry

#### **Priority Ceiling**

- Priority Ceiling for both resources: H
- R1: Normal preemption
- R2: Ceiling of 1 is H, PH is not higher than ceiling of all resources currently hold (1, which is H)
- R3: Normal Priority Inheritance



Deadlock resolved!

Prof. Erich Styger

Introduction


Architecture

Tasks

Priority Ceiling

- Nested/crossing resource usage
- ▶ Priority Ceiling:  $S_0 \Rightarrow H$ ;  $S_1 \Rightarrow M$ ;  $S_2 \Rightarrow M$

stop execute here



local ressource two

Infotronic

Introduction

Architecture

Tasks

Priority Ceiling

#### ► FreeRTOS Semaphore

- ► Does **NOT** implement Priority Inheritance mechanism
- Binary (single token) and counting (multiple token) semaphore
- ► Used for synchronization/IPC, does *not* have to be released
- xSemaphoreCreateBinary(), xSemaphoreCreateCounting()
- xSemaphoreTake(), xSemaphoreGive(), xSemaphoreDelete()
- FreeRTOS Mutex
  - Implements Priority Inheritance mechanism
  - Normal and recursive (can 'take' multiple times from same (task))
  - Used for resource locking, always has to be released
  - xSemaphoreCreateMutex(), vSemaphoreCreateRecursiveMutex()
  - xSemaphoreTake(), xSemaphoreGive(), xSemaphoreDelete()

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memo

Queues

Semaphore an

Learning Goals

Access to Shared Resource

Synchronization

journer Mars Rover

Priority Inheritance Prof Nested Priority Inherita Deadlocks

riority Ceiling

FreeRTOS Semaphore and Mutex

> eues with no Data tex Example

ry Semapnore mary

```
SemaphoreHandle t xSemaphore;
  xSemaphore = xSemaphoreCreateBinary();
  if (xSemaphore == NULL) {
the box is empty at this moment
    /* Failed! Not enough heap memory?. */
   else {
    /* The semaphore can now be used. Calling
        xSemaphoreTake() on the semaphore will fail until
        the semaphore has first been given. */
8
```

- Binary: one or zero token
- Creating Semaphore creates handle
- Check for NULL
- Semaphore token is not 'given' at creation time

Introduction

Architecture

Tasks

Creating Binary Semaphore


Tasks

Queues with no Data

```
#define xSemaphoreCreateBinary(xSemaphore) \
    xQueueGenericCreate((UBaseType t)1,
        semSEMAPHORE QUEUE ITEM LENGTH,
        queueQUEUE TYPE BINARY SEMAPHORE)
  #define xSemaphoreGive(xSemaphore) \
    xQueueGenericSend((xQueueHandle)xSemaphore, NULL, \
    semGIVE BLOCK TIME, queueSEND TO BACK)
  #define xSemaphoreTake(xSemaphore, xBlockTime) \
    xQueueGenericReceive ((xQueueHandle)xSemaphore, NULL, \
10
    xBlockTime, pdFALSE)
```

- API calls implemented as macros
- Macro semSEMAPHORE\_QUEUE\_ITEM\_LENGTH is 0
- ▶ Macro semGIVE BLOCK TIME is 0

# Mutex Example



- Two Tasks: A and B
- Access to shared resource guarded with Mutex

Prof. Erich Styger

Introduction

Architecture

Tasks

Mutex Example

- xSemaphoreTake() to get resource
- ► Task A can access resource

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrup

ernel Control

Tasks

Hooks

Heap Memor

zueues

Semaphore and Mutex

Learning Goals

Access to Shared Resource Synchronization

ojourner Mars Rove

iority Inversion

Priority Inheritance

ested Priority Inner eadlocks

Priority Ceilin

reeRTOS Semaph


Creating Binary Sen

ues with no Da

Mutex Example

ary Semaphi

#### Mutex Example



- ► Task B gets scheduled
- xSemaphoreTake() blocks Task B

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

Cernel Control

Tasks

Resource

Hook

Heap Memor

Queues

emaphore and Mutex

arning Goals

Access to Shared Resource

ojourner Mars Rover

riority Inversion

Priority Inheritance I

Deadlocks

Priority Ceilin

reeRTOS Semaph


Creating Binary Sem

Mutex Example

inany Samanhor

nary

### Mutex Example



- ➤ Task A returns lock on resource with xSemaphoreGive()
- Scheduler can resume Task B

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

ernel Control

Tasks

Hook

Heap Memo

Queues

Semaphore and

arning Goals

Access to Shared Resource

ojourner Mars Rover

Priority Inversion

riority Inheritance P lested Priority Inheri

Deadlocks

Priority Ceili

eeRTOS Semaphor utex

Creating Binary Sen

Mutex Example

Binary Semaph

mary

- Task B resumed by scheduler
- ► Call to xSemaphoreTake() succeeds
- Task B can access resource

Prof. Erich Styger

Introduction

Architecture

Tasks

Mutex Example



- Task B requests semaphore
- Blocking: xSemaphoreTake() used with 'wait forever' timeout

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

nel Control

Tasks

Hooks

Heap Memory

ueues

emaphore and

rning Goals

ccess to Shared Resource

journer Mars Rove

ority Inversion

ority Inheritance Pro

ested Priority Inherit

Priority Ceiling

FreeRTOS Semap

Mutex
Creating Binary Some

ueues with no Da

Mutex Example
Binary Semaphore Example

nary



- Semaphore not available
- ► Kernel suspends Task B

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hooks

Heap Memory

Queues

emaphore and lutex

rning Goals

ccess to Shared Resource

ojourner Mars Rove

riority Inversion

riority Inheritance P

Nested Priority Inhi Deadlocks

Deadlocks
Priority Ceiling

Priority Ceilii

reeRTOS Semaph

Creating Binary Sen

lutex Example

Binary Semaphore Example



- ► Task A gives Semaphore
- Semaphore contains item

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hook

Heap Memor

Queues

Semaphore and

arning Goals

ccess to Shared Resource

ojourner Mars Rove

riority Inversion

Priority Inheritance I

Nested Priority Inher

Deadlocks


Priority Ceilin

reeRTOS Semaph

Creating Binary Semi

utex Example

Binary Semaphore Example







- Task B was suspended and blocked
- Advent of semaphore resumes Task B

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

rnel Control

Tasks

Hook

Heap Memory

Queues

emaphore and

rning Goals

ccess to Shared Resource

journer Mars Rove

riority Inversion

Nested Priority Inheri

leadlocks

Priority Ceiling


reeRTOS Semapl

Creating Binary Semi

utex Example

Mutex Example

Binary Semaphore Example





- Task B processing first message
- Scheduler could resume Task A
- ► Task A can produce new token while Task B suspended

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interru

nel Control

Tasks

Hooks

Heap Memor

Queues

Semaphore and

arning Goals

Access to Shared Resource Synchronization

ojourner Mars Rove

riority Inversion

riority Inversion

riority Inheritance P

leadlocks

Priority Ceilin

eeRTOS Semapl

Mutex

ueues with no Da

Mutex Example
Binary Semaphore Example

mary



- Task B receives second semaphore
- ► Task B not blocked because semaphore is available

reeRTOS

Prof. Erich Styger

Introduction

Architecture

Cortex-M Interrupts

nel Control

Tasks

Hook:

Heap Memor

Queues

emaphore and

rning Goals

ccess to Shared Resource

ojourner Mars Rov

riority Inversion

Priority Inheritance I

vested Frionty Inne Deadlocks

Priority Ceilin

reeRTOS Semaph

Creating Binary Se

utex Example

Binary Semaphore Example

# Semaphore and Mutex: Summary

- Semaphore and Mutex are Queues with no data
- FreeRTOS Semaphore: simple tokens
- Problems of Priority Inversion and Deadlock
- Priority Inheritance Protocol
- Priority Ceiling Protocol
- FreeRTOS Mutex: Priority Inheritance protocol
- Binary, counting and recursive



FreeRTOS

Prof. Erich Styger

Introduction

Architecture

nel Control

Tasks

Hooks

Heap Memor

Queue:

Semaphore

earning Goals

Access to Shared Reso

Sojourner Mars Rov

Priority Inversion

Priority Inheritance Pro Nested Priority Inherita

riority Ceiling

reeRTOS Semapho

lutex

eues with no Data ex Example

Binary Semaphore Summary

#### Semaphore and Mutex: Lab Task

- Lab Assignment: Sem and Mutex
- Implement 'master' and 'slave' tasks
- Implement simple IPC between two tasks with binary semaphore
- Discuss semaphore/mutex creation before and after scheduler started



Prof. Erich Styger

Introduction

Tasks