



Probabilistic Risk Assessment (PRA) for Power Grids



Purpose. A structured overview of what Probabilistic Risk Assessment means for power systems, how it is formalized mathematically, and how it is used in planning and operations.

1. What PRA means for power grids

Probabilistic Risk Assessment (PRA) is the discipline of quantifying **risk** — the combination of *how likely* adverse events are and *how bad* their consequences are — rather than merely checking whitelisted worst cases. In power systems it answers questions like: *What is the expected unserved energy this year? What is the probability of a blackout exceeding 1 GW of lost load? Which contingencies contribute most to risk?*

The canonical conceptualization is the **Kaplan–Garrick risk triplet** (1981): risk is the set of triplets

$$R = \{\langle s_i, p_i, x_i \rangle\}_{i=1}^N$$

where s_i is a scenario (e.g. a contingency or sequence of failures), p_i its probability (or frequency), and x_i the consequence (e.g. load shed, energy not served, economic cost). PRA seeks to characterize this set and aggregate it into decision-relevant metrics.



Deterministic vs. probabilistic security. The traditional **N-1 (or N-k) criterion** requires the system to survive any single (or any k) component outage. It is binary, treats all contingencies as equally important, and ignores their likelihood. PRA instead *weights* contingencies by probability and severity, exposing the long tail of rare-but-severe and frequent-but-mild events that a deterministic screen hides.

Why probabilistic methods are increasingly necessary

- **Renewable penetration** — wind/solar inject correlated, weather-driven stochasticity into supply.
- **Demand uncertainty** — electrification (EVs, heat pumps) and weather-sensitive load.
- **Aging assets & correlated failures** — equipment wear, and common-cause events (storms, heat waves, wildfires) that defeat the independence assumptions behind N-1.
- **Cascading and systemic risk** — interdependent failures whose joint probability and impact cannot be captured by single-contingency screening.
- **Tighter margins** — markets and decarbonization erode the reserve that historically masked probabilistic exposure.

2. Where the randomness comes from

Source	Typical model	Notes
Component forced outages (lines, transformers, generators)	Two-state (up/down) Markov process; FOR = forced outage rate	Characterized by failure rate λ and repair rate μ ; availability $A = \mu/(\lambda + \mu)$
Generator partial outages	Multi-state capacity model	Derated states, not just up/down
Load	Chronological profiles, load-duration curves, forecast-error distributions	Often weather- and time-correlated
Wind / solar generation	Time series, copulas, scenario sets	Spatially and temporally correlated; correlated with

Source	Typical model	Notes
		load
Common-cause / common-mode failures	Beta-factor model, explicit weather/wildfire hazard layers	Breaks component-independence assumptions
Cascading propagation	Branching process, OPA / CASCADE, Markov transition models	Endogenous: failures change the probability of further failures
Cyber-physical / malicious	Attack trees, game-theoretic models	Non-stationary, adversarial probabilities

3. Formalization

3.1 State-space view

Let the system be described by a vector of component states $X = (X_1, \dots, X_m)$, each X_j drawn from an up/down set. The full **system state space** Ω has a probability measure induced by component models. For a state $s \in \Omega$ with probability $P(s)$, a **consequence (performance) function** $C(s)$ returns the impact (e.g. load curtailed by an optimal redispatch). Risk for a metric is the expectation

$$\text{Risk} = \mathbb{E}[C(X)] = \sum_{s \in \Omega} P(s) C(s),$$

or an integral when continuous variables (load, renewables) are involved. The two hard parts are (i) Ω is astronomically large ($\sim 2^m$ for binary components), and (ii) evaluating $C(s)$ requires solving a power-flow / optimization problem per state.

3.2 Component reliability model

For a repairable two-state component, the stationary unavailability is

$$U = \frac{\lambda}{\lambda + \mu} = \frac{\text{MTTR}}{\text{MTTF} + \text{MTTR}},$$

with λ the failure rate and μ the repair rate. Multi-state and time-varying (e.g. weather-dependent $\lambda(t)$) extensions are standard.

3.3 Core reliability / risk indices

Index	Meaning	Definition (sketch)
LOLP	Loss-of-load probability	Probability that load exceeds available capacity
LOLE	Loss-of-load expectation	Expected hours/days per year with shortfall; planning standard often 0.1 day/yr
EENS / EUE	Expected energy not served / unserved energy	Expected MWh of demand curtailed per year
LOLF / LOLD	Loss-of-load frequency / duration	How often, and for how long, shortfalls occur
EIR	Energy index of reliability	$1 - \text{EENS}/\text{total demand}$
SAIDI / SAIFI / CAIDI	Distribution-level customer indices	Avg interruption duration / frequency per customer

For the adequacy metrics, with G available generation and D demand (both random):

$$\text{LOLP} = \Pr(G < D), \quad \text{EENS} = \mathbb{E}[(D - G)^+] \cdot T.$$

3.4 Tail-risk metrics

Expectation alone hides catastrophic tails, so PRA increasingly borrows from financial risk theory:

- **Value at Risk** — $\text{VaR}_\alpha(C) = \inf\{c : \Pr(C \leq c) \geq \alpha\}$, the α -quantile of consequence.
- **Conditional VaR (Expected Shortfall)** — $\text{CVaR}_\alpha(C) = \mathbb{E}[C \mid C \geq \text{VaR}_\alpha(C)]$, the mean of the worst $1 - \alpha$ tail. CVaR is **coherent** and convex, which makes it attractive inside optimization (Rockafellar–Uryasev formulation).

3.5 Logical / structural models

- **Fault trees** — deductive, top-down: a top undesired event decomposed into AND/OR gates over basic component failures; yields minimal cut sets and top-event probability.
- **Event trees** — inductive, forward: branch an initiating event through success/failure of mitigations into outcome scenarios.

- **Reliability block diagrams** — series/parallel logic for system availability.
- **Bayesian networks** — directed graphical models capturing conditional dependence and common causes; support inference and updating.
- **Markov / semi-Markov models** — for repairable systems and sequences where rates matter.

3.6 Cascading-failure models

The distinctive feature of grid risk is **endogenous propagation**: a tripped line redistributes flow, overloading others. Common formal models:

- **OPA / CASCADE / branching-process** models — capture the heavy-tailed (often power-law) blackout-size distribution and the notion of self-organized criticality.
- **Influence / interaction graphs** estimated from simulation or historical outage data.
 - **DC/AC power-flow-based cascade simulators** with relay/protection logic and islanding.

4. Computational methods

Because Ω is enormous and $C(s)$ is expensive, method choice is the crux of practical PRA.

4.1 Analytical contingency enumeration

- Enumerate states up to order $N - 1$, $N - 2$, ... weighting by probability.
- Exact for low orders; combinatorial explosion beyond $N - 2$. Often paired with **state-space pruning** (drop states below a probability threshold) and **contingency screening / ranking**.

4.2 Monte Carlo simulation (MCS)

- **Non-sequential (state sampling)**: draw component states from their distributions independently per trial — efficient for adequacy indices that don't need chronology.
- **Sequential**: simulate a chronological year (or many), capturing duration, frequency, ramping, storage state-of-charge, and time-correlated renewables — needed for frequency/duration indices and storage.

- Estimator: $\widehat{\text{Risk}} = \frac{1}{n} \sum_k C(s_k)$, with convergence governed by the coefficient of variation; cost scales as $\mathcal{O}(\sigma^2/\varepsilon^2)$, independent of system size — its key advantage over enumeration.

4.3 Rare-event / variance-reduction techniques

Blackouts are rare, so crude MCS is slow. Specialized estimators:

- **Importance sampling** — bias sampling toward failure states, reweight by likelihood ratio.
- **Cross-entropy method** — adaptively learn a good importance-sampling distribution.
- **Subset simulation** — factor a rare event into a product of conditional, less-rare events.
- **Control variates, stratification, antithetic variates, Latin hypercube sampling.**
- **Splitting / RESTART** for sequential rare-event estimation.

4.4 Surrogate & learning-based acceleration

- Machine-learning surrogates for the security/feasibility classifier or for $C(s)$, to replace expensive OPF calls.
- Active learning to focus simulation near the feasibility boundary.

5. Consequence modeling

For each sampled state, the consequence is computed by a **remedial-action / optimal-power-flow** model. A typical minimum-load-shedding LP/NLP:

$$\min_{p, \Delta d} \sum_i \Delta d_i \quad \text{s.t. power balance, } |f_\ell| \leq f_\ell^{\max}, \underline{p} \leq p \leq \bar{p}, 0 \leq \Delta d \leq d$$

where Δd_i is load curtailed at bus i and f_ℓ line flows. Modeling choices that materially change risk estimates:

- **DC vs. AC** — DC-OPF is fast and convex but ignores voltages/reactive power/losses; AC captures voltage collapse and reactive limits but is nonconvex and may be infeasible (itself a risk signal).

- **Remedial actions modeled** — redispatch, switching, FACTS, load shedding priority/value (VOLL).
- **Protection & cascading logic** — whether overloads trip further elements.

Monetized risk often uses **Value of Lost Load (VOLL)**: $\text{cost} = \text{VOLL} \times \text{EENS}$.

6. How PRA is used in practice

6.1 Resource / generation adequacy

- Capacity planning and **capacity-market** sizing against a reliability standard (classically **1 day in 10 years**, i.e. LOLE = 0.1 day/yr).
- Computing **Effective Load Carrying Capability (ELCC)** of wind, solar, and storage — how much firm capacity a resource contributes.
- Tools/processes: GE-MARS, PLEXOS, SERVUM; ENTSO-E's **European Resource Adequacy Assessment (ERAA)**; PJM/MISO/CAISO adequacy studies.

6.2 Transmission planning

- Probabilistic comparison of reinforcement options by expected EENS reduction and risk-cost/benefit.
- ENTSO-E TYNDP cost-benefit analysis; CIGRE probabilistic-planning guidance.

6.3 Operational & online risk assessment

- **Operational risk** over the next hours: probability-weighted post-contingency severity given current topology, weather, and renewable forecasts.
- Drives reserve sizing, **probabilistic / risk-based security-constrained OPF and unit commitment** (chance constraints, scenario-based stochastic UC), and operator situational awareness.

6.4 Asset management & maintenance

- Risk-based maintenance and replacement prioritization (probability of failure $\times$ consequence), condition-based via Bayesian updating.

6.5 Resilience & extreme events

- Beyond reliability: hurricanes, wildfires, ice storms, and (increasingly) cyber threats — scenario/hazard-based PRA with spatial correlation, and resilience metrics over the event timeline (withstand–degrade–restore curve).



Standards & reference landscape. NERC reliability standards and the IEEE/PES reliability test systems (RTS-79, RTS-96, RTS-GMLC) for benchmarking; CIGRE WG reports on probabilistic planning; ENTSO-E ERAA/TYNDD methodologies; the foundational texts by **Billinton & Allan** (*Reliability Evaluation of Power Systems*) for indices and methods.

7. Quick mental model

flowchart LR

```

A["Uncertainty models<br>(outages, load, renewables)"] --> B["Sampling / enumeration<br>(MCS, importance sampling)"]
B --> C["State s with prob p(s)"]
C --> D["Consequence C(s)<br>DC/AC OPF + load shedding"]
D --> E["Aggregate over states"]
E --> F["Risk metrics<br>LOLE, EENS, VaR, CVaR"]
F --> G["Decisions<br>planning · operations · maintenance"]

```



8. Common pitfalls & open issues

- **Independence assumptions** that ignore weather-driven common-cause failures understate tail risk.
- **DC approximations** miss voltage-collapse-driven events relevant to AC-feasibility.
- **Convergence vs. rarity** — naive MCS badly under-samples catastrophic tails; rare-event methods are essential but introduce estimator bias if mis-tuned.
- **Data scarcity** for failure rates of rare/extreme events; reliance on expert priors → Bayesian treatment.

- **Metric choice** — expectation-based indices (EENS, LOLE) can be blind to low-probability high-impact events that CVaR/VaR expose.
- **Endogenous cascading** is genuinely hard: most tractable models approximate the propagation physics.