

2016.0 RANGE ROVER (LG), 501-08

EXTERIOR TRIM AND ORNAMENTATION

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION - DEPLOYABLE SIDESTEP CONTROL MODULE (DSCM)

For a detailed description of the retractable running board system and operation, refer to the relevant description and operation section of the workshop manual

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Deployable sidestep switch condition and installation ▪ Deployable sidestep hinges condition and installation ▪ Deployable sidestep motor(s) condition and installation	▪ Battery condition and state of charge ▪ Fuses ▪ Harnesses and connectors ▪ Deployable sidestep switch ▪ Deployable sidestep motor(s) ▪ Ignition switch ▪ Battery junction box ▪ Body control module ▪ CAN circuit(s)

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, check for diagnostic trouble codes (DTCs) and refer to the DTC index

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Deployable Sidestep Control Module \(DSCM\)](#) (100-00 General Information, Description and Operation).