

2016.0 RANGE ROVER (LG), 501-12

INSTRUMENT PANEL AND CONSOLE - LONG WHEEL BASE

FLOOR CONSOLE (G1699968)

REMOVAL AND INSTALLATION

REMOVAL

NOTES:

- Some components shown removed for clarity.
- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.



Vehicles with business seats

1. Refer to: Floor Console Extension (501-12B, Removal and Installation).




All vehicles

2. Refer to: Floor Console Upper Section (501-12B, Removal and Installation).

3.

CAUTION:

Make sure that the electrical harness is not trapped during the installation.




Torque: 9 Nm

4.

CAUTIONS:

- Make sure that the electrical harness is not trapped during the installation.
- Do not use excessive force to release the component.




E148005

5.

CAUTIONS:

- Make sure that the electrical harness is not trapped during the installation.
- Do not use excessive force to release the component.




E148006


6.

NOTE:


Repeat the procedure for the other side.



7.




8.



E147856

Torque: 3 Nm

9.



E148003


Torque: 9 Nm

CAUTION:



Make sure that the electrical harness is not trapped during the installation.

NOTE:

Do not disassemble further if the component is removed for access only.




11.




E148000

12.



E148011

13.




E148002

14.


CAUTION:

Make sure that the electrical harness is not trapped during the installation.




E148004

15.




16.



INSTALLATION

1.



2. To install, reverse the removal procedure.