

2016.0 RANGE ROVER (LG), 501-12

INSTRUMENT PANEL AND CONSOLE - LONG WHEEL BASE

REAR FLOOR CONSOLE (G1699662)

REMOVAL AND INSTALLATION

REMOVAL


NOTES:

- Some components shown removed for clarity.
- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.

1.

NOTE:

Repeat the procedure for the other side.



2.

NOTE:


Repeat the procedure for the other side.



3.

NOTE:

Repeat the procedure for the other side.




Torque: 50 Nm

4.

NOTE:

Repeat the procedure for the other side.




E145743

5.

NOTE:

Repeat the procedure for the other side.




E146116

Torque: 50 Nm

6.


NOTE:

Repeat the procedure for the other side.




7. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

8.




Torque: 10 Nm

9.




10.



11.

CAUTIONS:

- Do not use excessive force to release the component.
- Make sure that the electrical harness is not trapped during the installation.




12.

CAUTION:

Do not use excessive force to release the component.

NOTE:

Repeat the procedure for the other side.



E161280


13.

CAUTION:

Do not use excessive force to release the component.

NOTE:



Repeat the step for the other side.



E161281

Torque: 3.2 Nm

14.



E161282

Torque: 9 Nm


15.

CAUTION:


Make sure that the electrical harness is not trapped during the installation.

NOTE:

Do not disassemble further if the component is removed for access only.




16.




E161301

17.



E147755

18.




E148320

19.

NOTE:

Repeat the procedure for the other side.




E148323

20.

NOTE:


Repeat the procedure for the other side.



21.


CAUTIONS:

- Make sure that the electrical harness is not trapped during the installation.
- Do not use excessive force to release the component.




E148324

22.



E148327


23.



24.


CAUTION:

Make sure that the electrical harness is not trapped during the installation.



E148328

25.



INSTALLATION

1.

NOTE:

Install the trim retaining clips in the moulding prior to installing the components.



E149095

2. To install, reverse the removal procedure.