

2016.0 RANGE ROVER (LG), 501-05

INTERIOR TRIM AND ORNAMENTATION

'B' PILLAR LOWER TRIM PANEL (G1781318)

REMOVAL AND INSTALLATION

REMOVAL



NOTES:

- Removal steps in this procedure may contain installation details.
- Make sure that new plastic clips are installed and the original metal clips are installed to the trim if detached on removal.

1. Remove the B-pillar centre trim panel.
Refer to: B-Pillar Centre Trim Panel (501-05, Removal and Installation).

2. **NOTES:**

- Some components shown removed for clarity.
- Using a suitable trim tool remove the trim panel.
- Take care not to damage the component.





E167426

INSTALLATION

1.

NOTES:

- Some components shown removed for clarity.
- Take care not to damage the component.



E167427

2. Install the B-pillar centre trim panel.
Refer to: B-Pillar Centre Trim Panel (501-05, Removal and Installation).