

2016.0 RANGE ROVER (LG), 501-05

INTERIOR TRIM AND ORNAMENTATION

'B' PILLAR UPPER TRIM PANEL (G1509225)


REMOVAL AND INSTALLATION

REMOVAL

NOTES:

- Removal steps in this procedure may contain installation details.
- Make sure that new plastic clips are installed and the original metal clips are installed to the trim if detached on removal.


1.




2. Make the SRS system safe.

Refer to: Standard Workshop Practices (100-00 General Information, Description and Operation).

3.




4.



Torque: 40 Nm


5. Remove the B-pillar centre trim panel.
Refer to: B-Pillar Centre Trim Panel (501-05, Removal and Installation).

6.




Torque: 6 Nm

7.



8.



INSTALLATION

1. To install, reverse the removal procedure.

