

2016.0 RANGE ROVER (LG), 501-05

INTERIOR TRIM AND ORNAMENTATION

LUGGAGE COMPARTMENT UPPER TRIM PANEL (G1557507)

REMOVAL AND INSTALLATION

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.




All vehicles

1.


CAUTION:

Apply heatshrink or protective tape to the end of a suitable tool to protect the interior components.




2. Refer to: D-Pillar Trim Panel (501-05, Removal and Installation).

3.




Vehicles with heated rear seat

4.




5.




Vehicles without business seats

6.



7.



Torque: 50 Nm




Vehicles with business seats

8.




9.



Torque: 50 Nm

10.




11.




Torque: 50 Nm

12.




All vehicles

13.



Torque: 45 Nm



14.



E145532



Torque: 5.9 Nm

15.



E145531


16.



E145536

Torque: 6 Nm

17.



E148746

INSTALLATION

1. To install, reverse the removal procedure.