

2016.0 RANGE ROVER (LG), 501-10

SEATING - LONG WHEEL BASE

FRONT SEAT HEAD RESTRAINT MOTOR (G1702557)

REMOVAL AND INSTALLATION


REMOVAL

NOTES:

- Some variation in the illustrations may occur, but the essential information is always correct.
- Removal steps in this procedure may contain installation details.


1. Refer to: Front Seat (501-10, Removal and Installation).

2.




E143833

3.




E161742

4.





E161743

5.




E161744

6.



E161745


7.



E161746

Torque: 6.5 Nm

8.




E161747

9.


NOTE:

Repeat the step for the other side.




E161748

10.




E161749

11.




E161750

12.




13.




14.



15.




16.



17.

NOTE:

Repeat the step for the other side.





E161756

18.


NOTE:

Repeat the procedure for the other side.




E161757

19.



E161759



20.



E161760

Torque: 6 Nm

21.




E161761

Torque: 6 Nm


22.

NOTE:

Note the orientation of the clips.



23.



24.



E145605

25.



E143825

INSTALLATION

1. To install, reverse the removal procedure.