

2016.0 RANGE ROVER (LG), 501-10

SEATING - STANDARD WHEEL BASE

FRONT ROW PASSENGER SEAT CUSHION (G1521620)

REMOVAL AND INSTALLATION

REMOVAL

NOTES:


- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.



All vehicles

1. Refer to: [Front Row Seat Cushion Cover](#) (501-10B Seating - Long Wheel Base, Removal and Installation).

2.





E144197



Vehicles with heated front seats

3.




E144196





All vehicles

4.



E140686

INSTALLATION


1.

CAUTIONS:

- Make sure the component is aligned as shown.
- Make sure that the mating faces are clean and free of foreign material.

NOTES:

- Make sure that the adhesive strip is removed before installation.
- Install the occupant detection sensor with the adhesive side facing the cushion.




E140685

2.

CAUTION:

Make sure the component is aligned as shown.



E144168

3. To install, reverse the removal procedure.

