

2016.0 RANGE ROVER (LG), 501-10

SEATING - STANDARD WHEEL BASE

# REAR SEAT FORWARD/REARWARD MOTOR - VEHICLES WITH: REAR BUSINESS SEATS (G1545816)

REMOVAL AND INSTALLATION

---

---

## REMOVAL

### NOTE:


Removal steps in this procedure may contain installation details.

1. Refer to: [Rear Seat Massaging Lumbar Assembly - Vehicles With: Rear Business Seats](#) (501-10B Seating - Long Wheel Base, Removal and Installation).

2.


### NOTES:

- Make sure the wiring harness is routed correctly.
- Some variation in the illustrations may occur, but the essential information is always correct.




*Torque: 40 Nm*

3.




4.



E146152

5.




E146149

6.

**NOTE:**



Some variation in the illustrations may occur, but the essential information is always correct.



7.


**NOTE:**

Some variation in the illustrations may occur, but the essential information is always correct.




E145124

8.





E145214

9.





10.




E145213

11.



*Torque: 5 Nm*


12.



E146596



13.



---

## INSTALLATION

1. To install, reverse the removal procedure.