

2016.0 RANGE ROVER (LG), 206-05

PARKING BRAKE AND ACTUATION

PARKING BRAKE MODULE

[G1509076]

REMOVAL AND INSTALLATION

70.35.49	MODULE - ELECTRIC PARKING BRAKE - RENEW	ALL DERIVATIVES	0.2	USED WITHINS	+
----------	---	--------------------	-----	-----------------	---



REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2.




E145529

3.


NOTE:

If equipped.



Torque: 5 Nm

4.



Torque: 5 Nm

INSTALLATION

1. To install, reverse the removal procedure.
2. Calibrate the electric parking brake (EPB) using the diagnostic tool.

