

2016.0 RANGE ROVER (LG), 206-07

POWER BRAKE ACTUATION

BRAKE BOOSTER – RHD (G1772261)

REMOVAL AND INSTALLATION

70.50.01	BRAKE BOOSTER ASSEMBLY - RENEW	RIGHT HAND DRIVE	1.7	USED WITHINS	+
----------	--------------------------------	------------------	-----	--------------	---

REMOVAL

NOTE:


Removal steps in this procedure may contain installation details.

1. Refer to: [Secondary Bulkhead Right Panel](#) (501-02 Front End Body Panels, Removal and Installation).
2. Refer to: [Brake Master Cylinder - RHD](#) (206-06 Hydraulic Brake Actuation, Removal and Installation).


3.

NOTE:


Left hand drive shown right hand drive similar.



4.




5.



E147286


6.



E147283

Torque: 25 Nm

7.




E147287

8.

NOTE:

Left hand drive shown right hand drive similar.



E147285

Torque: 16 Nm

9.

NOTE:

Left hand drive shown right hand drive similar.



INSTALLATION



All vehicles

1. To install, reverse the removal procedure.



Vehicles with standard brakes

2. Refer to: [Brake System Bleeding - Vehicles With: Standard Brakes](#) (206-00 Brake System - General Information, General Procedures).



Vehicles with high performance brakes

3. Refer to: [Brake System Bleeding - Vehicles With: High Performance Brakes](#) (206-00 Brake System - General Information, General

Procedures).