

2016.0 RANGE ROVER (LG), 206-07

POWER BRAKE ACTUATION

ELECTRIC BRAKE VACUUM PUMP [G1676009]

REMOVAL AND INSTALLATION


REMOVAL

NOTES:


- Removal steps in this procedure may contain installation details.
- LHD shown, RHD is similar.

1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).
2. Refer to: [Right Air Cleaner](#) (303-12A Intake Air Distribution and Filtering - TDV6 3.0L Diesel - Gen 2/TDV6 3.0L Diesel, Removal and Installation).


3.



4.



5.



Torque: 10 Nm

INSTALLATION

1. To install, reverse the removal procedure.