

2016.0 RANGE ROVER (LG), 419-01

ANTI-THEFT – ACTIVE

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

Electric Steering Column Lock (ESCL)

For a detailed description of the anti-theft - active operation, refer to the relevant description and operation section of the workshop manual. REFER to: Anti-Theft - Active (419-01A, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

NOTE:

Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.

- 1. Verify the customer concern
- 2. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Stop/start switch ▪ Electric steering column lock ▪ Smart key	▪ Fuses ▪ Electrical harnesses ▪ Harness connectors ▪ Smart key battery ▪ Body Control Module (BCM, controls +12 volt supply to electric steering column lock and software logic for electric steering column lock control) ▪ Keyless Vehicle Module (KVM) ▪ RF receiver ▪ Instrument pack (provides electrical ground circuit to electric steering column lock) ▪ CAN circuits

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
- 4. If the cause is not visually evident check the system for any logged diagnostic trouble codes (DTCs) and proceed to the DTC index

DTC INDEX

For a complete list of all diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00.

REFER to: [Diagnostic Trouble Code Index - DTC: Keyless Vehicle Module \(KVM\)](#) (100-00 General Information, Description and Operation) / [Diagnostic Trouble Code Index - DTC: Electric Steering Column Lock Control Module \(ESCL\)](#) (100-00 General Information, Description and Operation) /

Diagnostic Trouble Code Index - DTC: Body Control Module (BCM) (100-00
General Information, Description and Operation).