

2016.0 RANGE ROVER [LG], 419-01

ANTI-THEFT – PASSIVE

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the anti-theft - passive system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Anti-Theft - Passive](#) (419-01B Anti-Theft - Passive, Description and Operation).

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: (100-00 General Information)

[Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#)
(Description and Operation),

[Diagnostic Trouble Code Index - DTC: Keyless Vehicle Module \(KVM\)](#)
(Description and Operation).