

2016.0 RANGE ROVER (LG), 414-01

BATTERY, MOUNTING AND CABLES

ELECTRIC POWER INVERTER CONVERTER [G1661164]

REMOVAL AND INSTALLATION

REMOVAL

WARNING:


This procedure can only be carried out after the vehicle has been decommissioned, by an approved person.

NOTES:


- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.

1. Refer to: [Hybrid Electric Vehicle Battery Pack Cradle](#) (414-01 Battery, Mounting and Cables, Removal and Installation).


2.



3.




4.




Torque: 10 Nm


5.





6.



7.



8.




Torque: 9 Nm

9.


NOTE:

Do not disassemble further if the component is removed for access only.




E158523

10.



1




E158524

2

Torque: 9 Nm


11.



E158525


Torque: 25 Nm

12.




E158526

13.




E158527

14.



1




2

E158528

Torque: 10 Nm

15.



E158529

Torque: 10 Nm

INSTALLATION

1. To install, reverse the removal procedure.