

2016.0 RANGE ROVER (LG), 412-02

AUXILIARY CLIMATE CONTROL

FUEL FIRED BOOSTER HEATER BLOWER (G1604769)

REMOVAL AND INSTALLATION


REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.


1. Refer to: Fuel Fired Booster Heater (412-02, Removal and Installation).

2.




E155480

3.



E155493

4.



E155444

5.




E155491

6.

NOTE:

Remove the terminals from the connector as indicated in order to replace the component.



E155490

INSTALLATION

1. To install, reverse the removal procedure.