

2016.0 RANGE ROVER (LG), 412-01


CLIMATE CONTROL

DESCRIPTION AND OPERATION

COMPONENT LOCATION

NOTE:

RHD (right-hand drive) installation shown, LHD (left-hand drive) installation is mirror image.



E140689

ITEM	DESCRIPTION
1	Center front face vents
2	Duct air temperature sensor - center front face
3	Demist duct (2 off)
4	Demist vent (2 off)
5	Driver foot duct
6	Outer front face vent (2 off)
7	Duct air temperature sensor - right front foot, rear foot and rear face
8	Rear foot duct (2 off)
9	Rear face duct (2 off)
10	Rear face vents

11	Duct air temperature sensor - left front foot, rear foot and rear face
12	Front passenger foot duct
13	Air filter
14	Side window vent (2 off)
15	Outer front face duct (2 off)
16	Side window duct (2 off)

OVERVIEW

The air distribution and filtering system consists of:

- Air ducts
- Air vents
- Air filter.

DESCRIPTION

AIR DUCTS

The air ducts consist of tubes connected between the climate control assembly and the various air vents around the vehicle interior. The center sections of the air ducts for the side window vents are integrated into the structure of the instrument panel. The rear foot ducts connect to the climate control assembly via ducts integrated into the structure of the floor console.

Eight duct air temperature sensors are installed to provide more accurate temperature control. The sensors are installed in the front foot ducts, the center front face ducts and in the rear foot and face ducts. The sensors are NTC (negative temperature coefficient) thermistors, which are connected to the ATC (automatic temperature control) module.

For additional information, refer to: [Control Components](#) (412-01A Climate Control, Description and Operation).

AIR VENTS

Adjustable air vents are installed in the face outlets of the instrument panel and the floor console. The remainder of the outlets have fixed vents integrated into the end of the air duct or installed in the trim panel connected to the air duct.

AIR FILTER

The air filter is a combination pollen and odor filter installed in the air inlet duct, over the blower inlet.