

2016.0 RANGE ROVER (LG), 412-02

AUXILIARY CLIMATE CONTROL

ELECTRIC BOOSTER HEATER

[G1521560]

REMOVAL AND INSTALLATION

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.





All vehicles

1. Disconnect the battery ground cable.
Refer to: Specifications (414-00, Specifications).

2.

NOTE:

RHD illustration shown, LHD is similar.





E148287

3.

NOTE:

RHD illustration shown, LHD is similar.




E146055


4.

NOTE:


Repeat the procedure for the other side.



5.




6.



Vehicles with business seats


7.



8.

NOTE:

Repeat the procedure for the other side.




All vehicles

9.

NOTE:


Repeat the procedure for the other side.



10.

NOTE:


Repeat the procedure for the other side.



11.


NOTE:

Repeat the procedure for the other side.




E 147746

12.



E149291


13.




14.




15.




16.



17.



18.



INSTALLATION

1. To install, reverse the removal procedure.