

2016.0 RANGE ROVER (LG), 414-01

BATTERY, MOUNTING AND CABLES

# ELECTRIC POWER INVERTER CONVERTER COOLANT PUMP

[G1675941]

REMOVAL AND INSTALLATION

---

---

## REMOVAL

### NOTE:

Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.  
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2. **WARNING:**


Make sure to support the vehicle with axle stands.

Raise and support the vehicle.

3. Refer to: [Engine Undershield](#) (501-02 Front End Body Panels, Removal and Installation).

4. Refer to: [Cooling System Partial Draining and Vacuum Filling](#) (303-03F Engine Cooling - TDV8 4.4L Diesel, General Procedures).


5.




6.

**CAUTION:**

Be prepared to collect escaping coolant.



7.



*Torque: 6 Nm*

---

## INSTALLATION

1. To install, reverse the removal procedure.