

2016.0 RANGE ROVER (LG), 413-08

INFORMATION AND MESSAGE CENTER

HEAD UP DISPLAY [G1770469]

REMOVAL AND INSTALLATION


REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.


1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).
2. Refer to: [Instrument Panel Upper Section](#) (501-12A Instrument Panel and Console - Standard Wheel Base, Removal and Installation).

3.




Torque: 1.5 Nm

4.




5.



Torque: 1.5 Nm

6.



Torque: 5 Nm

INSTALLATION

1. To install, reverse the removal procedure.

