

2016.0 RANGE ROVER (LG), 415-01

INFORMATION AND ENTERTAINMENT SYSTEM

INFORMATION AND ENTERTAINMENT DISPLAY

[G1521686]

REMOVAL AND INSTALLATION


REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.


1. Disconnect the battery ground cable.
Refer to: Specifications (414-00, Specifications).

2.





E147085

3.





E147428

4.



5.



E147430

INSTALLATION

1. To install, reverse the removal procedure.