

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

HEADLAMP SWITCH (G1549877)

REMOVAL AND INSTALLATION

REMOVAL

-
1. Remove the left steering column multifunction switch. For additional information, refer to: [Steering Column Multifunction Switch](#) (211-05 Steering Column Switches, Removal and Installation).
-

INSTALLATION

-
1. To install reverse the removal procedure.