

2016.0 RANGE ROVER (LG), 418-00

MODULE COMMUNICATIONS NETWORK

BATTERY JUNCTION BOX

[G1509760]

REMOVAL AND INSTALLATION


REMOVAL

NOTES:


- Some variation in the illustration may occur, but the essential information is always correct.
- Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable
Refer to: [Specifications](#) (414-01 Battery, Mounting and Cables, Specifications).


2.



3.



4.




Torque: 9 Nm


5.

NOTE:

Component shown removed for clarity.



6.



Torque:

M8 Nut **12 Nm**

M5 Nut **5.5 Nm**

INSTALLATION

1. To install, reverse the removal procedure.