

2016.0 RANGE ROVER (LG), 418-00

MODULE COMMUNICATIONS NETWORK

CENTRAL JUNCTION BOX

[G1937917]

REMOVAL AND INSTALLATION

REMOVAL

NOTES:



- Some variation in the illustrations may occur, but the essential information is always correct.
- Some components shown removed for clarity.
- Removal steps in this procedure may contain installation details.
- RHD shown, LHD is similar.



All vehicles

1. Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2.




E146055



Right-hand drive vehicles

3.




E149758





All vehicles


4.




5.




6.



E186690



7.




E186691

INSTALLATION



All vehicles



1.



2.


CAUTION:

Make sure the fuse cover is held in place when installing the wiring connectors.



Torque: 9 Nm

3.




E186689

4.


CAUTION:

Make sure the fuses are correctly installed.



E188437

5.




E149759



Right-hand drive vehicles

6.





E149758



All vehicles

7.



E146055

8. Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).