

2016.0 RANGE ROVER (LG), 418-00

MODULE COMMUNICATIONS NETWORK

QUIESCENT CURRENT CONTROL MODULE (G1561112)

REMOVAL AND INSTALLATION



REMOVAL

NOTES:

- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.


1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2.



E145529

3.



E150157

Torque: 9 Nm

INSTALLATION

1. To install, reverse the removal procedure.
2. If a new component has been installed, configure using Land Rover approved diagnostic equipment.