

2016.0 RANGE ROVER (LG), 418-02

WIRING HARNESSES

SUSPENSION AIR SUPPLY UNIT WIRING HARNESS (G1704051)

REMOVAL AND INSTALLATION


REMOVAL

NOTES:

- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.


1. Refer to: [Air Suspension Compressor](#) (204-05 Vehicle Dynamic Suspension, Removal and Installation).

2.



E161582


3.



E161581


Torque: 1 Nm

4.



Torque: 10 Nm


5.



6.



CAUTION:

Before replacing the upper cover, make sure that the intake hose and filter are fitted in their correct positions. Failure to follow this instruction may cause damage to the component.



E161584


7.



E161585

Torque: 10 Nm

8.



E161586

INSTALLATION

1. To install reverse the removal procedure.