

2016.0 RANGE ROVER (LG), 303-05

ACCESSORY DRIVE - TDV6 3.0L DIESEL

ACCESSORY DRIVE BELT TENSIONER (G1509474)

REMOVAL AND INSTALLATION

	TENSIONER				
86.10.06	- GENERATOR DRIVE BELT - RENEW	3000 CC, TDV6	0.2	USED WITHINS	+

REMOVAL

NOTE:


Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.
Refer to: Specifications (414-00, Specifications).
2. Refer to: Engine Cover - TDV6 3.0L Diesel (501-05, Removal and Installation).


3.

NOTES:

- Note the fitted position of the accessory drive belt.
- Engine shown removed for clarity.



4.



Torque: 47 Nm

INSTALLATION

1.

CAUTIONS:

- Make sure that the accessory drive belt is correctly located on each pulley.
- Clean and inspect the accessory drive belt pulleys for damage.

To install, reverse the removal procedure.