

2016.0 RANGE ROVER (LG), 307-05

AUTOMATIC TRANSMISSION/TRANSAXLE EXTERNAL CONTROLS -
VEHICLES WITH: 8HP70 8-SPEED AUTOMATIC TRANSMISSION AWD

EMERGENCY PARK POSITION RELEASE LEVER (G1509731)

REMOVAL AND INSTALLATION

44.15.92	TRANSMISSION	ALL DERIVATIVES	1.5	USED WITHINS	+
	EMERGENCY				
	RELEASE				
	LEVER - RENEW				

REMOVAL

NOTES:

- Removal steps in this procedure may contain installation details.
- Some variation in the illustrations may occur, but the essential information is always correct.

1.


WARNING:

Make sure to support the vehicle with axle stands.

Raise and support the vehicle.

2. Refer to: [Engine Undershield](#) (501-02 Front End Body Panels, Removal and Installation).

3.




Torque:

M10 60 Nm

M6 10 Nm

4.





Torque: **10 Nm**

5.

CAUTION:


Care must be taken to avoid damaging the surrounding components.




E148741

6. Refer to: [Floor Console Upper Section](#) (501-12A Instrument Panel and Console - Standard Wheel Base, Removal and Installation).

7.




8.



Torque: 3 Nm

9.




INSTALLATION

NOTE:

Some variation in the illustrations may occur, but the essential information is always correct.

1.



To install, reverse the removal procedure.

