

2016.0 RANGE ROVER (LG), 307-01

AUTOMATIC TRANSMISSION/TRANSAXLE - VEHICLES WITH: 8HP70 8-SPEED AUTOMATIC TRANSMISSION AWD

INPUT SHAFT SEAL (G1509711)


REMOVAL AND INSTALLATION

		3000 CC, TDV6,			
44.20.17	OIL SEAL - INPUT SHAFT - RENEW	DIESEL, WITH PARTICULATE FILTER, WITH DIESEL EXHAUST FLUID	6.1	USED WITHINS	+

SPECIAL TOOL(S)



100-012
Slide Hammer




100-012-01

100-012-01

Slide Hammer
Adapter



307-613



E84067

307-613

Holding Pins,
Torque Converter



308-375

308-375

Remover, Input and
Output Seal



E131592

JLR-308-845

Installer, Input Shaft
Seal

REMOVAL

CAUTION:

Be prepared to collect escaping fluids.

NOTE:

Some variation in the illustrations may occur, but the essential information is always correct.

1. Refer to: [Transmission - TDV6 3.0L Diesel](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Removal).
Refer to: [Transmission - TDV8 4.4L Diesel](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Removal).
Refer to: [Transmission - V8 N/A 5.0L Petrol/V8 S/C 5.0L Petrol](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Removal).

2.




E149764

Special Tool(s): 307-613

3.

CAUTIONS:

- Discard the seal.
- Care must be taken to avoid damage to the seal register and running surface.



E130877


Special Tool(s): 100-012, 100-012-01, 308-375

INSTALLATION

1.

CAUTION:

Install a new seal.




Special Tool(s): [JLR-308-845](#)

2.

CAUTION:

Make sure the torque converter is fully located into the oil pump drive.



E138283

3. Install the transmission and transfer gearbox.
Refer to: [Transmission - TDV6 3.0L Diesel](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Installation).
Refer to: [Transmission - TDV8 4.4L Diesel](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Installation).
Refer to: [Transmission - V8 N/A 5.0L Petrol/V8 S/C 5.0L Petrol](#) (307-01B Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed Automatic Transmission AWD, Installation).
4. Refer to: [Transmission Fluid Level Check](#) (307-01C Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed - Hybrid Electric Vehicle - Automatic Transmission – AWD, General Procedures).
Refer to: [Transmission Fluid Level Check - V8 N/A 5.0L Petrol/V8](#)

[S/C 5.0L Petrol](#) (307-01B Automatic Transmission/Transaxle -
Vehicles With: 8HP70 8-Speed Automatic Transmission AWD,
General Procedures).