

2016.0 RANGE ROVER (LG), 303-14

ELECTRONIC ENGINE CONTROLS - TDV6 3.0L DIESEL

ENGINE COOLANT TEMPERATURE SENSOR (G1509555)

REMOVAL AND INSTALLATION

18.30.10	SENSOR - COOLANT TEMPERATURE (ECT SENSOR) - RENEW	3000 CC, TDV6	0.1	USED WITHINS	+
----------	---	------------------	-----	-----------------	---

REMOVAL

CAUTION:


Make sure that all openings are sealed. Use new blanking caps.

NOTE:

Removal steps in this procedure may contain installation details.

1. Refer to: [Engine Cover - TDV6 3.0L Diesel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

2.




3.

CAUTIONS:

- Be prepared to collect escaping fluids.
- The seal is to be reused unless damaged.
- Make sure that the mating faces are clean and free of foreign material.

NOTE:

Release the locking tang to remove the ECT sensor.



INSTALLATION

1.

NOTE:

Make sure that all the component mating faces are clean.

To install, reverse the removal procedure.

2. Check and top up coolant level.