

2016.0 RANGE ROVER (LG), 303-14

ELECTRONIC ENGINE CONTROLS - TDV6 3.0L DIESEL

ENGINE OIL PRESSURE SENSOR (G1509558)

REMOVAL AND INSTALLATION

12.60.50	SWITCH - OIL PRESSURE - RENEW	3000 CC, TDV6	0.1	USED WITHINS	+
----------	--	------------------	-----	-----------------	---

REMOVAL


NOTES:

- Some variation in the illustrations may occur, but the essential information is always correct.
- Some components shown removed for clarity.


1. Remove the engine cover.

Refer to: [Engine Cover - TDV6 3.0L Diesel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

2.



3.




INSTALLATION

1.


CAUTION:

Make sure that the mating faces are clean and free of foreign material.



Torque: 14 Nm

2.



3. Install the engine cover.

Refer to: [Engine Cover - TDV6 3.0L Diesel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).