

2016.0 RANGE ROVER (LG), 303-14

ELECTRONIC ENGINE CONTROLS - TDV6 3.0L DIESEL

OIL TEMPERATURE SENSOR

[G1509564]

REMOVAL AND INSTALLATION

18.30.41	SENSOR - OIL TEMPERATURE - RENEW	3000 CC, TDV6	0.4	USED WITHINS	+
----------	--	------------------	-----	-----------------	---

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2.

WARNING:

Make sure to support the vehicle with axle stands.

Raise and support the vehicle.

3. Remove the oil pan.

Refer to: [Oil Pan](#) (303-01F Engine - SDV6 3.0L Diesel - Hybrid Electric Vehicle, Removal and Installation).


- 4.



E122599

Torque: 12 Nm

- 5.



E122586

Torque: 12 Nm

INSTALLATION

1. To install, reverse the removal procedure.