

2016.0 RANGE ROVER (LG), 303-01

ENGINE - TDV6 3.0L DIESEL - GEN 2/TDV6 3.0L DIESEL

DUAL MASS FLYWHEEL - TDV6 3.0L DIESEL - GEN 2, VEHICLES WITH: HYBRID SYSTEM [G1675939]

REMOVAL AND INSTALLATION

REMOVAL

NOTES:


- Some variation in the illustrations may occur, but the essential information is always correct.
- Component shown removed for clarity.

1. Refer to: [Transmission](#) (307-01C Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed - Hybrid Electric Vehicle - Automatic Transmission – AWD, Removal).

2.

CAUTIONS:

- It is essential that absolute cleanliness is observed when working on the hybrid drive assembly. Always cover any open orifices using lint free non-flocking material to prevent the ingress of foreign matter. Failure to follow this instruction may result damage to the components.
- Discard the component.



E159641


3.

CAUTION:

Remove the bolts in the indicated sequence.

NOTE:

This step requires the aid of another technician.




E159610

4.

CAUTION:

Discard the components.




E159707

INSTALLATION

1.

CAUTION:

Make sure that new components are installed.




2.

CAUTION:

Tighten the bolts in the sequence shown.

NOTE:

This step requires the aid of another technician.




E159610

Torque: 15 Nm

3.

CAUTIONS:

- Make sure that a new component is installed.
- Tighten the bolts in the sequence shown.




E159643

Torque: 15 Nm

4.

NOTE:

Make sure that the hybrid drive assembly is fully engaged to the transmission.



E138283

5. Refer to: [Transmission](#) (307-01C Automatic Transmission/Transaxle - Vehicles With: 8HP70 8-Speed - Hybrid Electric Vehicle - Automatic Transmission – AWD, Installation).