

PUBLISHED: 11-JUL-2016
2014.0 RANGE ROVER (LG), 303-01


ENGINE - V8 S/C 5.0L PETROL

CRANKSHAFT FRONT SEAL (G1509341)

REMOVAL AND INSTALLATION

12.21.14	OIL SEAL - CRANKSHAFT - FRONT - RENEW	5000 CC, AJ V8, SUPERCHARGED	2.3	USED WITHINS
----------	--	------------------------------------	-----	-----------------

SPECIAL TOOL(S)



303-1434

Remover/Installer, Front
Crankshaft Seal

REMOVAL


NOTE:

Removal steps in this procedure may contain installation details.
Some variation in the illustrations may occur, but the essential information is
always correct.

1. Disconnect the battery ground cable.
Refer to: Specifications (414-00 Battery and Charging System - General
Information, Specifications).

2. Refer to: Crankshaft Pulley (303-01 Engine - V8 S/C 5.0L Petrol, Removal and Installation).

3.



Special Tool(s): 303-1434

Torque: 26 Nm

INSTALLATION

1.



CAUTIONS:

- Do not over tighten the crankshaft front seal. Failure to follow this instruction may result in damage to the vehicle.
- Take extra care not to damage the seal.

To install, reverse the removal procedure.

