

2016.0 RANGE ROVER (LG), 303-08

ENGINE EMISSION CONTROL - TDV6 3.0L DIESEL - GEN 2/TDV6 3.0L DIESEL

LEFT EXHAUST GAS RECIRCULATION VALVE - TDV6 3.0L DIESEL - GEN 2

[G1875419]

REMOVAL AND INSTALLATION					
17.45.16	VALVE - EGR - LH - RENEW	3000 CC, TDV6	1.4	USED WITHINS	+

REMOVAL

NOTES:


- Removal steps in this procedure may contain installation details.
- Some illustrations may show the engine removed for clarity.
- Make sure that all openings are sealed.

1. Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).
2. Refer to: [Cooling System Partial Draining and Vacuum Filling](#) (303-


03A Engine Cooling - TDV6 3.0L Diesel - Gen 2/TDV6 3.0L Diesel, General Procedures).

3. Refer to: [Secondary Bulkhead Centre Panel - TDV6 3.0L Diesel](#) (501-02 Front End Body Panels, Removal and Installation).

4.




5.



6.


NOTE:

Discard the gasket.




Torque: 5.5 Nm

7.




Torque: 10 Nm


8.



9.



10.



Torque: 10 Nm

INSTALLATION

1. To install reverse the removal procedure.
2. If a new unit is installed, configure using the approved diagnostic tool.