

PUBLISHED: 18-JUN-2017
2015.0 RANGE ROVER (LG), 303-00

ENGINE SYSTEM - GENERAL INFORMATION

LEAKAGE TEST USING SMOKE TEST EQUIPMENT (G1445299)



CAUTION:

The compressed air line supply pressure must be between 3.5 and 12 bar (50 and 175 psi) for the smoke test equipment to function correctly. Do not exceed this pressure. Failure to follow this instruction may result in damage to the smoke test equipment.



NOTES:


- The vehicle battery must be in good condition and fully charged before carrying out this procedure.
- On vehicles with 3.0L TDV6, it will be necessary to insert smoke at both air cleaner outlet pipes independently if the right hand turbocharger and associated hoses are to be tested.
- In some cases it may be necessary to remove undertrays, trim or engine covers to obtain access to all potential leak locations.
- Some variation in the illustrations may occur, but the essential information is always correct.
- For further information regarding operation of the test equipment refer to the manufacturers operators manual supplied with the kit.

1.



WARNING:

Use an additional support to prevent the hood from falling if the smoke test equipment is secured to the hood. Failure to follow this instruction may result in personal injury.



Install the smoke test equipment to a suitable location under the hood.

2. Connect a suitable compressed air line to the smoke test equipment.
3. Connect the smoke test equipment positive power cable to the battery positive terminal.


4. **WARNING:**

Do not connect the smoke test equipment negative cable to the battery negative terminal.

Connect the smoke test equipment negative cable to a suitable body ground point.

5. **NOTE:**

A flashing green light indicates low battery voltage. In this case, place the battery on charge and make sure that the battery is fully charged before using the smoke test equipment.




Observe the power indicator lamp on the smoke test equipment. Make sure that a continuous green light is displayed.

6.



NOTES:

- In some cases it may be necessary to remove the air cleaner(s) to allow access to the air cleaner outlet pipes.
- In some cases it will be necessary to cap one of the air cleaner outlet pipes. Use the blanking caps supplied in the kit to cap the open orifice.




Disconnect the air cleaner outlet pipe(s).

7.



NOTE:

Make sure the smoke test equipment adapter is a good fit to the air cleaner outlet pipe. This must be an air tight seal.



Connect the smoke test equipment supply hose to the air cleaner outlet pipe.


1. Install the appropriate adapter to the air cleaner outlet pipe.
2. Connect the smoke test equipment supply hose to the adapter link hose.

8.



NOTES:

- The flow control valve must be in the fully open position.
- Smoke is produced for 5 minutes. The smoke test equipment will automatically switch off after this period of time.



Switch the smoke test equipment on.

9. Remove the oil filler cap, and observe until a constant flow of smoke is visible leaving the oil filler orifice. Install the oil filler cap.

10.



NOTE:

The longer smoke is allowed to exit from a leak, the more fluorescent dye will be deposited at a leak location.

Using the torch supplied in the kit set to white light, look for escaping smoke. Alternatively, use the ultraviolet light to look for fluorescent dye deposits at the source of a leak.

