

2016.0 RANGE ROVER (LG), 310-03

SPEED CONTROL - TDV6 3.0L DIESEL

SPEED CONTROL SENSOR

[G1509667]

REMOVAL AND INSTALLATION

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).

2.


WARNING:

Make sure to support the vehicle with axle stands.

Raise and support the vehicle.

3. Refer to: [Front Bumper Cover](#) (501-19 Bumpers, Removal and Installation).

4.



E145878

Torque: 5 Nm

INSTALLATION

1. To install, reverse the removal procedure.
2. Refer to: [Speed Control Sensor Adjustment](#) (310-03D Speed Control - TDV8 4.4L Diesel, General Procedures).