

2016.0 RANGE ROVER (LG), 308-07

TRANSFER CASE - VEHICLES WITH: SINGLE SPEED TRANSFER CASE

TRANSFER CASE CONNECTING SLEEVE SEALS

[G1727534]

REMOVAL AND INSTALLATION

SPECIAL TOOL(S)



100-012

Slide Hammer



E52536

307-520

Installer, Output
Shaft Seal



E158796

JLR-308- 930

Installer, Oil Seal



E158798

JLR-308- 932

Remover, Oil Seal

REMOVAL

NOTE:

Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable.

Refer to: Specifications (414-00 Battery and Charging System - General Information, Specifications).

- 2.

WARNING:

Make sure to support the vehicle with axle stands.

Raise and support the vehicle.



3. Remove the transfer case.

Refer to: Transfer Case - GTDi 2.0L Petrol (308-07B, Removal).

- 4.

CAUTION:

Care must be taken to avoid damage to the seal register and running surface.




E156808

Special Tool(s): [100-012](#), [JLR-308-932](#)

INSTALLATION

1.



E158632

Special Tool(s): [307-520](#), [JLR-308-930](#)

2. Install the transfer case.

Refer to: Transfer Case - GTDi 2.0L Petrol (308-07B, Installation).

3. Connect the battery ground cable.

Refer to: Specifications (414-00 Battery and Charging System - General Information, Specifications).