
Every stop: median tilt error 3.6° with the motor stopped, 2.8° during the restore
motor stopped
during the restore (1.3 s)
Max tilt error [°]
20
15
10
5
0
*
M2
M2
M1
M3
M4
M5
M6
M5
Stops in flight order (stopped motor)
* EKF heading reset (compass) during this stop