
Every stop: median tilt error 3.9° with the motor stopped, 3.7° during the restore
motor stopped
during the restore (1.3 s)
Max tilt error [°]
0
2
4
6
8
10
12
*
M1
M2
M3
M4
M6
M5
M6
M5
M2
M1
M2
Stops in flight order (stopped motor)
* EKF heading reset (compass) during this stop