

Remove longer pins from plastic guides of 90° headers.















Begin placing 3.5mm components.

All PCB parts in place...


...soldered and trimmed.













This document is a work in progress and will be completed after the BETA phase of production.