Rk3308 WIFI Interface Documentation

发布版本:1.0

作者: Jacky.Ge

日期:2019.3.29

文件密级:公开资料

概述

该文档旨在介绍RK3308 Devicelo库中接口。

芯片名称

RK3308

读者对象

本文档(本指南)主要适用于以下工程师:

技术支持工程师

软件开发工程师

修订记录

日期	版本	作者	修改说明
2019-3-29	V1.0	Jacky.Ge	初始版本

Rk3308 WIFI Interface Documentation

- 1、概述
- 2、接口说明
- 3、使用示例

1、概述

该代码模块集成在libDevicelo.so动态库里面,基于wpa封装的wifi操作接口。

2、接口说明

RK_WIFI_RUNNING_State_e

WIFI的几种状态定义

```
typedef enum {
    RK_WIFI_State_IDLE = 0,
    RK_WIFI_State_CONNECTING,
    RK_WIFI_State_CONNECTFAILED,
    RK_WIFI_State_CONNECTFAILED_WRONG_KEY,
    RK_WIFI_State_CONNECTED,
    RK_WIFI_State_DISCONNECTED
}
RK_WIFI_State_DISCONNECTED

RK_WIFI_RUNNING_State_e;
```

• RK_WIFI_CONNECTION_Encryp_e

WIFI加密类型,包括无密码、WPA和WEP三种方式

```
typedef enum {
    NONE = 0,
    WPA,
    WEP
} RK_WIFI_CONNECTION_Encryp_e;
```

• RK_WIFI_INFO_Connection_s

WIFI状态信息,参考wpa_cli-iwlan0 status

```
typedef struct {
1
2
       int id;
3
       char bssid[20];
4
      char ssid[64];
5
      int freq;
      char mode[20];
6
7
      char wpa_state[20];
8
       char ip_address[20];
9
       char mac_address[20];
10 } RK_WIFI_INFO_Connection_s;
```

- int RK_wifi_register_callback(RK_wifi_state_callback cb)
 注册WIFI状态回调接口,在WIFI状态改变是回调
- int RK_wifi_ble_register_callback(RK_wifi_state_callback cb) ble wifi回调接口,用于ble配网时回调状态
- int RK_wifi_running_getState(RK_WIFI_RUNNING_State_e* pState)获取当前WIFI状态,成功返回0
- int RK_wifi_running_getConnectionInfo(RK_WIFI_INFO_Connection_s* pInfo)获取当前WIFI连接信息
- [int RK_wifi_enable_ap(const char* ssid, const char* psk, const char* ip)] 根据传入的ssid、psk和ip开启softAp

• int RK_wifi_disable_ap()

关闭softAp

• int RK_wifi_scan(void)

执行WIFI sacn操作, 参见wpa_cli -iwlan0 scan

char* RK_wifi_scan_r(void)

获取WIFI scan结果,返回JSON。参见wpa_cli -iwlan0 scan_r

char* RK_wifi_scan_r_sec(const unsigned int cols)

获取WIFI scan结果指定列,返回JSON。参见RK_wifi_scan_r(void)

bssid / frequency / signal level / flags / ssid

使用5位二进制从左到右依次代表上述数据,例如RK_wifi_scan_r_sec(0x01)获取bssid数据, RK_wifi_scan_r_sec(0x10)获取ssid数据,RK_wifi_scan_r_sec(0x1F)获取所有数据

int RK_wifi_connect(const char* ssid, const char* psk)

以默认WPA加密方式连接指定热点

int RK_wifi_connect1(const char* ssid, const char* psk, const RK_WIFI_CONNECTION_Encryp_e
 encryp, const int hide)

参见RK_wifi_connect接口,拓展加密类型,ssid隐藏性参数

int RK_wifi_disconnect_network(void)

断开WIFI连接

• int RK_wifi_set_hostname(const char* name)

设置hostname

• int RK_wifi_get_hostname(char* name, int len)

获取hostname

• int RK_wifi_get_mac(char *wifi_mac)

获取mac地址

• int RK_wifi_has_config(void)

网络是否配置过

int RK_wifi_ping(void)

以ping的方式判断网络是否连接

3、使用示例

```
#include <stdio.h>
#include <string.h>
#include <DeviceIo/Rk_wifi.h>

int _RK_wifi_state_callback(RK_WIFI_RUNNING_State_e state)

printf("_RK_wifi_state_callback state:%d\n", state);
```

```
8
        return 0;
9
    }
10
    int main(int argc, char **argv)
11
12
13
        // 注册WIFI状态回调
14
        RK_wifi_register_callback(_RK_wifi_state_callback);
15
16
        // 设置hostname后获取打印
17
        char hostname[16];
        RK_wifi_set_hostname("RKWIFI");
18
19
        memset(hostname, 0, sizeof(hostname));
20
        RK_wifi_get_hostname(hostname, sizeof(hostname));
        printf("hostname:%s\n", hostname);
21
22
23
        // 获取MAC地址并打印
24
        char mac[32];
25
        memset(mac, 0, sizeof(mac));
26
        RK_wifi_get_mac(mac);
27
        printf("mac:%s\n", mac);
28
29
        // 如果有配置过WIFI, enable wifi自动连接到配置的WIFI
        // 否则连接到指定WIFI
30
31
        if (RK_wifi_has_config()) {
32
            RK_wifi_enable(1);
33
        } else {
34
            RK_wifi_enable(1);
            RK_wifi_connect("TP-LINK_C734BC", "12345678");
35
36
        }
37
        for (;;);
38
39
        // 断开WIFI并关闭WIFI模块
40
        RK_wifi_enable(0);
41
42
        return 0;
43
   }
44
```