Content Indexing	PDF Number of pages
01.Index	1
02.Change List	2
03.Block Diagram	3
04.Power tree-RK805-1	4
05.System Power-PMIC RK805-1	5
06.RK3328 Power	6
07.RK3328 OSC/PLL/OTP/SARADC	7
08.RK3328 DDR Controler	8
09.RK3328 eMMC Controler/TF	9
10.RK3328 USB2 PHY/USB3 PHY	10
11.RK3328 SDIO/UART/I2C/I2S/IR	11
12.RK3328 HDMI PHY	12
13.RK3328 AV Interface	13
14.RK3328 FEPHY	14
15.RAM DDR3 4x16bit	15
16.TF/SD Card	16
17.Flash-eMMC	17
18.USB Port	18
19.HDMI OUT Port	19
20.IR Receiver	20
21.AV OUT Port	21
22.10/100/1000M-ExternalPHY	22
23.Debug UART2	23
24.WIFI+BT_2T2R	24
25.CH7101B HDMI TO VGA	25
26.GL3523-QFN76 USB HUB	26
27.USB7-8	27
28.POWER-HV	28

RK3328

Bill of Materials

Header:

Item\tPart\tDescription\tPCB Footprint\tReference\tQuantity\tOption


Combined property string:


{Item}\t{Value}\t{Description}\t{PCB Footprint}\t{Reference}\t{Quantity}\t{Option}


Note:


Component parameter description


- 1. DNP stands for component not mounted temporarily
- 2. If Value or option is DNP, which means the area is reserved without being mounted










































5 3 2











5 4 3





JEĆWAY) TF/SD Card Document Number Rev RK3328_BOX_Demo3 1.0 Sheet Friday, May 26, 2017 28

