




POWER INPUT SECTION


C2 470uF need place if needed.
It is there to prevent resets.
JP1/5V Short -> This is a jumper
for using MT3608 boost converter.
First try this, instead of using
Capacitor. I think this time it
will work.




3.3V REGULATOR




ISP PIN FOR PROGRAMMING




FTDI Header




LED FOR EACH ARM




MOTOR Driver Section




Capacitor Bank Section



NRF24L01 SMD Module



BMP280



MPU6050