
5V IN
PS MIO
UART
USB SLAVE
ETHERNET
USB HOST
J5/J6 ON:Master
J5/J6 OFF:OTG
SD
QSPI
JTAG
3.3V GND
1.5V GND
1.8V GND
1.0V GND
PWR
DONE
ZYNQ
ALINX
HDMI_O
JTAG