001. Why Analog?

Kai Wang

June 11, 2021

Introduction

We are surrounded by "digital" devices.

Introduction

We are surrounded by "digital" devices.









Introduction

We are surrounded by "digital" devices.










Do we still need analog design?

Electronic system perform two principal functions:


Electronic system perform two principal functions: (1) sense (receive) a signal;

Electronic system perform two principal functions: (1) sense (receive) a signal; (2) process and extract information from it.

Electronic system perform two principal functions: (1) sense (receive) a signal; (2) process and extract information from it.




Electronic system perform two principal functions: (1) sense (receive) a signal; (2) process and extract information from it.



• Processing is preferably carried out in digital domain.


Electronic system perform two principal functions: (1) sense (receive) a signal; (2) process and extract information from it.




- Processing is preferably carried out in digital domain.
- Sensing still needs to be carried out in analog domain and demands high performance design.

Let us take the neural recoding system as another example.

Let us take the neural recoding system as another example.




Let us take the neural recoding system as another example.



Needs low power circuits which incorporated with analog design:


Let us take the neural recoding system as another example.



Needs low power circuits which incorporated with analog design:

• to permit the use of a small battery for days or weeks;

Let us take the neural recoding system as another example.




Needs low power circuits which incorporated with analog design:


- to permit the use of a small battery for days or weeks;
- to minimize the rise in the chip's temperature, which could otherwise damage the patients's tissue.

Analog design is not only used in an ADC field.

Analog design is not only used in an ADC field. When we transmit digital signals via a USB cable, they would be **distored**.




Analog design is not only used in an ADC field. When we transmit digital signals via a USB cable, they would be **distored**.




• One possible solution is to adopt an ADC when receive these signals and recover them in the digital domain.

Analog design is not only used in an ADC field. When we transmit digital signals via a USB cable, they would be **distored**.



 One possible solution is to adopt an ADC when receive these signals and recover them in the digital domain. (enery hungry @ large bps)

Analog design is not only used in an ADC field. When we transmit digital signals via a USB cable, they would be **distored**.




- One possible solution is to adopt an ADC when receive these signals and recover them in the digital domain. (enery hungry @ large bps)
- We need to use an analog equalizer instead of an ADC to save energy @ large bps.

Analog Design Is in Great Demand

Another way to illustrate the importance of analog design is the numbers of analog papers published in ISSCC (Internal Solid-State Circuit Conference).

Analog Design Is in Great Demand

Another way to illustrate the importance of analog design is the numbers of analog papers published in ISSCC (Internal Solid-State Circuit Conference).



With the development of semiconductor industry, we comes into the nanometer design stage, which arise some interesting and difficult problems.

• Transistor Imperfections:

With the development of semiconductor industry, we comes into the nanometer design stage, which arise some interesting and difficult problems.

• Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages:

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.
- Power Comsumption:

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.
- Power Comsumption: scaling lowers the power comsumption of digital circuits, but not analog circuits.

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.
- Power Comsumption: scaling lowers the power comsumption of digital circuits, but not analog circuits.
- Circuit Complexity:

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.
- **Power Comsumption**: scaling lowers the power comsumption of digital circuits, but not analog circuits.
- Circuit Complexity: modern analog design is usually composed of hundreds of transistors, which needs SPICE and MATLAB to simulate it.
- PVT Variation:

With the development of semiconductor industry, we comes into the nanometer design stage, which arise some interesting and difficult problems.

- Transistor Imperfections: MOSFETs become faster at the costs of its analog properties.
- Declining Supply Voltages: many circuits haven't survived such supply reduction and been discarded.
- **Power Comsumption**: scaling lowers the power comsumption of digital circuits, but not analog circuits.
- Circuit Complexity: modern analog design is usually composed of hundreds of transistors, which needs SPICE and MATLAB to simulate it.
- **PVT Variation**: device and circuit parameters varies with the fabrication process, supply voltage, and ambient temperature.

Why do we still need analog design?

Why do we still need analog design?

• The real world is composed of analog elements, we need **analog** design to incorporate them into the digital domain.

Why do we still need analog design?

- The real world is composed of analog elements, we need **analog** design to incorporate them into the digital domain.
- In most case, we need to adopt a low power design, which also needs **analog** design.

Why do we still need analog design?

- The real world is composed of analog elements, we need **analog** design to incorporate them into the digital domain.
- In most case, we need to adopt a low power design, which also needs **analog** design.
- Large bps calls for **analog** design to meet such frequency and save energy.

Why do we still need analog design?

- The real world is composed of analog elements, we need **analog** design to incorporate them into the digital domain.
- In most case, we need to adopt a low power design, which also needs **analog** design.
- Large bps calls for **analog** design to meet such frequency and save energy.

Despite these reasons, papers associated with analog design published in ISSCC occupies a great proportion.

Why do we still need analog design?

- The real world is composed of analog elements, we need **analog** design to incorporate them into the digital domain.
- In most case, we need to adopt a low power design, which also needs **analog** design.
- Large bps calls for **analog** design to meet such frequency and save energy.

Despite these reasons, papers associated with analog design published in ISSCC occupies a great proportion.

However, starting an analog design will encounter with lots of problems causing by the scaling down in modern technology.

Thank you!