

About this device

This device is here to reassure your family. It has no camera and no microphone — it only detects whether there is movement, never what you are doing.

- The light briefly turns on with every movement it detects. That is all it shows.
- If no movement is detected for a long time, your family receives a message — so they, or your care provider, can check that everything is alright.
- Privacy: no one — not even your family — can see from this device when or how often you move. Only an unusually long, uninterrupted silence is reported.
- You decide. If you want to switch the device off for a while — for example during a holiday or a longer absence — simply unplug it. Plug it back in when you return.

This device does not replace family care or professional care. It is only an extra safety net.