


For initial assembly, the shock absorber is installed in its softest position. If after some time a readjustment will be required, proceed according to the following

1. Remove shock absorber and fix in a vise in vertical position at lower eye - with the plunger rod pointing upward - (see fig. 60).







4. Starting from the original position, turn 1/2 or more revolutions clockwise - depending on the extent of the shock absorbing force to be checked - then stretch the shock absorber somewhat apart in order to be able to disengage the adjusting device (see fig. 62) (Max. readjustment 4 revolution halves).




Fig. 62

5. By spreading and compressing with some intuition it will be easy to ascertain whether 2 shock absorbers have identical adjustment.